

# Service Bulletin

*19-059* 

May 17, 2019 Version 1

# Safety Recall: 2007-11 CR-V Incorrect Installation of the Takata Front Passenger's Airbag Inflator

#### **AFFECTED VEHICLES**

Year	Model	Trim	VIN Range
2007-11	CR-V	ALL	Check the iN VIN status for eligibility.

#### **BACKGROUND**

Some dealers incorrectly installed passenger front airbag inflators under various campaigns to replace the inflators. The incorrect installation of the inflators may have damaged the airbag assembly. Additionally, the airbag may not deploy as designed. If the inspection reveals the inflator is not installed correctly, do not replace only the inflator. If the inflator is incorrectly installed make sure to replace the front passenger's airbag module assembly.

There are several bulletins with similar years and models. Make sure to do an iN VIN status inquiry and follow the indicated service bulletin.

#### **CUSTOMER NOTIFICATION**

Owners of affected vehicles will be sent a notification of this campaign.

Do an iN VIN status inquiry to make sure the vehicle is shown as eligible.

Some vehicles affected by this campaign may be in your used vehicle inventory.

Failure to repair a vehicle subject to a recall or campaign may subject your dealership to claims or lawsuits from the customer or anyone else harmed as a result of such failure. To see if a vehicle in inventory is affected by this safety recall, do a VIN status inquiry before selling it.

#### **CORRECTIVE ACTION**

Inspect the front passenger airbag inflator and, if the inflator is not installed correctly, replace the airbag module assembly.

### NOTES

These notes are applicable only when the airbag assembly is replaced:

- Write the serial number and part number from the side of the new replacement front passenger's airbag module box on the repair order.
- To properly dispose of the original inflator, you must remove it from the airbag module. See REMOVE THE INFLATOR FROM THE ORIGINAL AIRBAG MODULE.
- A new inflator box must be ordered and the original inflator must be returned in the box.

**CUSTOMER INFORMATION:** The information in this bulletin is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely maintain your vehicle. These procedures should not be attempted by "do-it-yourselfers," and you should not assume this bulletin applies to your vehicle, or that your vehicle has the condition described. To determine whether this information applies, contact an authorized Honda automobile dealer.

- To return the inflator, follow the shipping instructions outlined in the parts information bulletin A15-0002, Inflator Kit Return Process.
- Place the original airbag module (without the inflator) in the airbag module box that the replacement came in. It may be called in by American Honda.

#### PARTS INFORMATION

**Inspection Only** 

Part Name	Part Number	Quantity
Washer Nut (6 mm)	90321-SP0-A80	3

**Airbag Module Replacement** 

Part Name	Part Number
Refer to the parts catalog using the VIN to ensure the correct airbag module and ancillary parts are ordered.	Refer to the parts catalog.

- Make sure the airbag inflator is removed from the original airbag module. See Remove the Inflator From the Original Airbag Module section of this bulletin.
- The new airbag module box must be used to return the old airbag module **without the inflator** to American Honda (if requested). Be careful not to damage the airbag module box.
- To return the inflator, follow the shipping instuctions outlined in the parts information bulletin A15-0002, *Inflator Kit Return Process*.
- Parts staff can scan the part number and serial number from the outside of the box into the warranty claim by using the Controlled Part Serial No. screen and scanning the applicable information. Refer to the Job Aid *Ordering and Managing Replacement Inflators* for more information.

#### **WARRANTY CLAIM INFORMATION**

- To avoid non-payment of warranty claims for airbag module assembly replacement, the new airbag module part number and serial number must be included in each claim. For more information, refer to step 1 of AIRBAG MODULE INSTALLATION.
- To avoid a warranty claim being charged back to your dealership, follow the normal warranty part retention rules. American Honda may call in the original airbag module.
- The serial number is encoded into the bar code label attached to the outside of the box. If your dealership uses a scanner, you can scan the serial number into the claim.
- The part number is encoded into a barcode attached to the outside of the box. If your dealership uses a scanner, you can scan the part number into the claim.
- If you confuse the serial number and part number when entering the claim information, your claim will automatically be rejected.
- Template IDs are not included because there are many model/trim/color variations.


• There are several service bulletins with similar years and models. Make sure you file your warranty claim under the correct bulletin. If you file your claim under the wrong bulletin, your claim will be debited.

Operation Number	Description	Flat Rate Time	Defect Code	Symptom Code	Failed Part Number
7540A4	Remove the airbag module, inspect the inflator installation, and re-install the original airbag module.	0.4 hr	6NG00	M4O00	77820-SWA-A20ZA
7541F7	Remove the airbag module, inspect the inflator installation, and replace the airbag module.	0.4 hr	6NG00	M4O00	77820-SWA-A20ZA

Skill Level: Repair Technician

#### **INSPECTION PROCEDURE**

- If the VIN status inquiry indicates that the vehicle is subject to any open safety recalls, including a driver's airbag inflator campaign/recall, make sure to also complete those recall repairs before returning the vehicle to the customer. If you are unable to complete any open recall, advise the customer of the recall status and when the recall could be completed.
- Make sure you have the anti-theft code for the audio and navigation system (if applicable), then write down the frequencies for the audio unit's preset buttons.
- Make sure you have reviewed the SRS Precautions and Procedures in the service information before doing the repair.
- 1. Turn the ignition to ON, and check if the SRS indicator comes on for about 6 seconds, then goes off.
  - If the indicator comes on, then turns off after about 6 seconds, go to step 2.
  - If the indicator does not come on, or if it stays on, contact your DPSM for assistance.
- 2. Disconnect the battery negative cable, and wait at least 3 minutes before continuing.
- 3. Remove the front passenger's airbag module (assembly). Refer to the applicable model's service information.
- 4. Set the airbag module assembly face down on a clean soft surface with the mounting studs facing toward you.



- 5. Inspect the plastic collars on the inflator.
  - If the long collar is on your left side, the inflator installation is **GOOD**. Go to AIRBAG MODULE INSTALLATION to install the original airbag module assembly.
  - If the long collar is on your right side, the inflator installation is **NO GOOD**. Replace the airbag module with a new one. Order a new airbag module and install it as shown in AIRBAG MODULE INSTALLATION.

#### **AIRBAG MODULE INSTALLATION**

1. **For airbag module replacement only -** Write the serial number and part number from the side of the new front replacement passenger's airbag module box on the RO. For the warranty claim to be paid, **the new front passenger's airbag module part number and serial number** must be included in the warranty claim.



- 2. Install the passenger's airbag module (assembly). Refer to the applicable model's service information.
- 3. After reconnecting the 12-volt battery, turn the ignition to ON, and check if the SRS indicator comes on for about 6 seconds, then goes off. If the indicator does not come on, or comes on and stays on, follow normal troubleshooting.
- 4. Set the clock (for vehicles without navigation), and enter the anti-theft code for the audio and navigation system (if applicable).
- 5. **For airbag module replacement only -** Remove the inflator from the original airbag module. Refer to REMOVE THE INFLATOR FROM THE ORIGINAL AIRBAG MODULE.
- 6. **For airbag module replacement only -** Give your warranty clerk the RO that includes the replacement front passenger's airbag module serial number and replacement part number. For the warranty claim to be paid the **new front replacement passenger's airbag module part number and serial number** must be included in the warranty claim.

#### REMOVE THE INFLATOR FROM THE ORIGINAL AIRBAG MODULE

1. Order a new inflator box from XPO to return the original airbag module inflator. Use the contact information below:

Primary Contact: Tel#: 1-210-250-5079

Email: SCFieldAction.14305@xpo.com

- 2. Remove the harness from the inflator bracket.
- 3. Short the red and yellow wires.

#### NOTE

Depending on the vehicle, you must cut the red or yellow wires to remove the inflator, and both sets of wires must be shorted to prevent accidental deployment.


3.1. Cut the red wires about 2 inches from the inflator.

## NOTE

There may be some protective tube covering the wires that needs to be cut away to access the wires.

Cut the harness on this side.






3.2. Strip away about 1 inch of the red wire insulation, then twist the wires together.







- 3.3. Tape the twisted ends with electrical tape.
- 3.4. Cut the yellow wires about 2 inches from the inflator.




3.5. Strip away about 1 inch of the yellow wire insulation, then twist the wires together.







- 3.6. Tape the twisted ends with electrical tape.
- 3.7. Remove the four inflator nuts.



4. Remove the inflator bracket.

# NOTE

You can only remove one of the brackets, as the other is welded to the airbag housing.



INFLATOR BRACKET Do not reuse. 5. Remove the inflator by pulling it out.



- 6. Put the original inflator into the new inflator box acquired from XPO. Make sure there is no other hardware in the box because if the package rattles, it will not be accepted by the courier.
- 7. Follow the shipping instructions outlined in PIB A15-0002 to return the undeployed inflator.
- 8. Place the original airbag module (without the inflator) in the airbag module box that the replacement came in. Properly fill out and attach a warranty claim tag to it. The original airbag module may be called in by AHM.

**END**