



INFINITI

VOLUNTARY RECALL CAMPAIGN

Classification: RS22-008	Reference: ITB22-033	Date: August 15, 2022
-----------------------------	-------------------------	--------------------------

VOLUNTARY SAFETY RECALL CAMPAIGN 2006-2007 M35/M45; FRONT PASSENGER AIR BAG INFLATOR INSPECTION

CAMPAIGN ID #: PC908
APPLIED VEHICLES: 2006-2007 M35/M45 (Y50)

**Check Service COMM or Dealer Business Systems (DBS)
National Service History to confirm campaign eligibility.**

INTRODUCTION

Infiniti is conducting this voluntary safety recall campaign, on certain specific model year 2006-2007 M35/M45 vehicles, to inspect and, if necessary, replace the front passenger air bag inflator. This service will be performed at no charge to the client for parts or labor.

IDENTIFICATION NUMBER


Infiniti has assigned identification number PC908 to this campaign. This number must appear on all communication and documentation of any nature dealing with this campaign.

DEALER RESPONSIBILITY

It is the retailer's responsibility to check Service COMM or Dealer Business Systems (DBS) National Service History for the campaign status on each vehicle falling within the range of this voluntary safety recall which for any reason enters the service department. This includes vehicles purchased from private parties or presented by transient (tourist) clients and vehicles in a retailer's inventory. **Federal law requires that new vehicles in retailer inventory which are the subject of a safety recall must be corrected prior to sale. Failure to do so can result in civil penalties by the National Highway Traffic Safety Administration.** While federal law applies only to new vehicles, Infiniti strongly encourages retailers to correct any used vehicles in their inventory before they are retailed.

Bulletins are intended for use by qualified technicians, not 'do-it-yourselfers'. Qualified technicians are properly trained individuals who have the equipment, tools, safety instruction, and know-how to do a job properly and safely. **NOTE:** If you believe that a described condition may apply to a particular vehicle, DO NOT assume that it does. See your Infiniti retailer to determine if this applies to your vehicle.

REPAIR OVERVIEW



REQUIRED SPECIAL TOOLS

- Air Bag Module Support J-51315-KIT
 - New tool part number NI-51315-KIT




Figure 1

REQUIRED SPECIAL TOOLS (continued)

Quick Scan Tool (J-52352)

- Each retailer has been previously shipped one Quick Scan Tool (J-52352).
 - New tool part number NI-52352.



Figure 2

Additional tools may be purchased from Tech•Mate: www.TechMateTools.com or 1-833-397-3493.

SERVICE PROCEDURE

WARNING

To avoid the risk of death or severe personal injury, follow all cautions, warnings, and notices in the Electronic Service Manual (ESM) when working on or near a Supplemental Restraint System (SRS), such as an air bag.

NOTICE

To avoid damage to the interior trim, handle interior trim carefully and with clean hands. If not handled carefully with clean hands, damage and/or stains to these parts may occur. Use protective covers as needed.

Inspect the Front Passenger Air Bag Inflator

1. Remove the glove box.
 - Refer to the ESM: **BODY > INSTRUMENT PANEL > SERVICE INFORMATION > INSTRUMENT PANEL ASSEMBLY > GLOVE BOX > Removal and installation**
2. Using a light, inspect the area shown in Figure 3 to determine if the air bag inflator is metal or has a plastic end cap.
 - If the front passenger air bag inflator has a plastic end cap (Figure 5 and Figure 7 on page 6), no replacement is required. Reassemble the instrument panel in the reverse order of disassembly.

NOTE: The plastic end cap may be a different color than shown.

 - If the front passenger air bag inflator is metal (no plastic end caps [Figure 6 and Figure 8 on page 6]), continue to step 3 on page 7 for front passenger air bag inflator replacement.



Figure 3




Figure 4

Examples of Air Bag Inflators

Air Bag Inflator with plastic end caps
(OK Condition)




Figure 5

Air Bag Inflator with no end caps
(NG Condition)



Figure 6



Figure 7



Figure 8

Register the New Front Passenger Air Bag Inflator

- Write down the radio settings.

Presets	1	2	3	4	5	6
AM						
FM 1						
FM 2						
SAT 1						
SAT 2						
Bass	Treble		Balance	Fade		Speed Sen. Vol.

- Turn the ignition OFF.
- Disconnect both battery cables, negative cable first.
- Wait a minimum of 3 minutes before continuing to step 7.
- Remove the new passenger air bag module from its packing and register the module's serial number as outlined in steps 8 - 13 on pages 7 - 10.
- Attach the Quick Scan Tool (J-52352 or NI-52352) to a CONSULT PC's USB port.



Figure 9

9. Open ASIST, select **Tech Support Info**, and then **Inventory Vehicle Actions**.



Figure 10

10. Select **CLICK HERE...** next to **Airbag to VIN Registration**.



Figure 11

11. Using the Quick Scan Tool (J-52352 or NI-52352), scan the bar code (VIN) located on the driver (LH) side B-pillar label.

HINT:

- Make sure the VIN label is clean.
- Hold tool J-52352 or NI-52352 about six (6) inches away from the VIN label.
- Hold down the trigger until tool J-52352 or NI-52352 is finished scanning the VIN label.
- Some VIN labels may not scan quickly.
- The VIN will populate automatically. See Figure 14 on page 10.
- If needed, the VIN can be entered manually.



Figure 12

12. Use the quick scan tool to scan the bar code (serial number) on the new air bag inflator shipping box.

- The serial number will automatically populate below the VIN. See Figure 14 on page 10.
- If needed, the serial number can be entered manually.




Figure 13

13. Once the **VIN** and **Airbag Serial Number** fields are populated, select **Submit**.

[Airbag to VIN Registration](#)

11/28/2016 1:36:32 PM

Please enter/scan the VIN and Airbag Inflator Serial Number

Dealer Code

Key Number

VIN

Airbag Serial Number ←

Figure 14

Replace the Front Passenger Air Bag Inflator

14. Remove the front passenger air bag module.
- Refer to the ESM: **RESTRAINTS > SUPPLEMENTAL RESTRAINT SYSTEM (SRS) > SERVICE INFORMATION > FRONT PASSENGER AIR BAG MODULE > Removal and Installation**
15. Securely mount the air bag module support in a vise.




Figure 15

16. Unclip the wire harness from the wire harness guides.




Figure 16

17. Attach the FX brackets to the air bag module support, as shown in Figure 17.
- Make sure the convex parts of the brackets are in the UP position.
 - Use bolts and nuts supplied with the support.
 - Leave the bolts/nuts slightly loose to allow for positioning of the module.




Figure 17

18. Attach the air bag module to the FX brackets in the support, as shown in Figure 18.
- Use the bolts and nuts supplied with the support.
 - Make sure the arrow on the air bag module is pointing down.




Figure 18

19. Make sure the module is centered in the support.

NOTE: Centering the module in the support will allow access to the inflator securing nuts through the slots in the support.

20. Tighten all of the mounting bolts and nuts that hold the module and brackets to the support.



Figure 19

21. Using a suitable cutting tool, carefully cut a few inches of the yellow corrugated harness cover in the area shown in Figure 20.

- Take care not to cut the wires inside the corrugated cover.




Figure 20

22. Attach two (2) shorting pins to the air bag inflator wire harness, as shown in Figure 21.

- Make sure to pair the wires from each end of the inflator.
 - **Blue with White**
 - **Red with Yellow**
- Use an insulation displacement type wire connector as a shorting pin.
- Refer to the Parts Information for additional connector/shorting pin information.




Figure 21

23. Using a suitable cutting tool, cut off the connector end of the wire harness, as shown in Figure 22.



Figure 22

24. Remove the four (4) nuts from the air bag module that hold the air bag inflator in place and discard, they will not be used.



Figure 23



Figure 24

25. Remove the air bag inflator stopper and discard, it will not be used.




Figure 25

26. Push the left side of the air bag inflator out of the air bag module.
- Twist the air bag inflator to a position that will allow the wire harness and harness connector to fit through the opening.




Figure 26

27. Pull the inflator completely out of the module from the right side.
- Set the old inflator in the clean working area and make sure it does not roll and fall to the floor.



Figure 27

28. Remove the air bag module from the air bag module support, and then place the air bag module on a clean working surface.

29. Install the new left side air bag inflator stopper bracket with two (2) new nuts finger tight.




Figure 28

30. Reinstall the air bag module to the air bag module support.

NOTE: Ensure the arrow on the air bag module is pointing down, as shown in Figure 29.




Figure 29

31. Remove the new air bag inflator from the box, and then install it into the air bag module, as show in Figure 30.

- The large end of the air bag inflator will be inserted into the air bag module first.




Figure 30

32. Align the air bag inflator alignment tab and then insert it through the hole in the left side air bag inflator stopper bracket.




Figure 31

33. Install a new right side air bag inflator stopper bracket with two (2) new nuts finger tight.




Figure 32

34. Push on the right side air bag inflator stopper bracket (Figure 33) to ensure the air bag inflator is sitting against the left side and right side air bag inflator stopping brackets (Figure 34 and Figure 35).




Figure 33




Figure 34




Figure 35

35. Torque the four (4) air bag inflator stopper bracket nuts in the sequence shown in Figure 36.

- Air bag inflator stopper bracket nut torque: 3.9 N•m (0.4 kg-m, **34 in.-lb**)




Figure 36

36. Remove the dust cover stickers on the right and left side of the air bag inflator.




Figure 37




Figure 38

37. Attach the wire harness connectors to each end of the air bag inflator.

IMPORTANT: Make sure to attach the wire harness connectors to the correct side of the air bag inflator (Figure 39). Once an air bag inflator wire harness connector is connected, it cannot be disconnected.




Figure 39

- Make sure the T shape at the inflator end aligns with the T shape of the wire harness connector.




Figure 40

- Make sure harness connector is fully engaged / seated (Figure 41).




Figure 41

38. Remove the air bag module from the air bag module support, and then place the air bag module on a clean working surface.

39. Clip the new wire harness into the wire harness guides




Figure 42

40. Install the front passenger air bag module into the vehicle.
- Refer to the ESM: **RESTRAINTS > SUPPLEMENTAL RESTRAINT SYSTEM (SRS) > SERVICE INFORMATION > FRONT PASSENGER AIR BAG MODULE > Removal and Installation**
41. Reconnect both battery cables, positive battery cable first.
42. Reset/reinitialize systems as needed.
- Refer to the ESM: **GENERAL INFORMATION > GENERAL INFORMATION > SERVICE INFORMATION > INSPECTION AND ADJUSTMENT > ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL**
43. Reset the clock and radio settings.
44. Turn the ignition ON and observe the air bag warning light.
- The air bag warning light should illuminate for 7 seconds and then turn off.
NOTE: If the Air Bag Warning light does not operate as described above there may be an issue not covered by this campaign. Refer to ASIST and the appropriate Service Manual for additional diagnostic and repair information.
45. Return the removed (old / non-deployed) air bag inflator in the box that the new air bag inflator arrived in.
- Follow the return instructions on the next page.

RETURN INSTRUCTIONS

NOTE

NOTE: International (including Mexico and Canada), Hawaii, Alaska, Puerto Rico, and US Virgin Islands dealers **CANNOT** follow below shipping instructions. Instead, dealerships in these locations **MUST** contact the following Takata/Menlo USA representative directly for shipping instructions: Miguel Prigadaa – Tel#: 210-250-5078 or Email: MLGTakataRestraints_International@XPO.com

NOTE: For Continental US 48 State dealerships, please follow steps 1-8 below.

- Specific to Step 4 below:
 - Follow step 4a if you receive the updated NON-FedEx label. Proceed to step 5.
 - Follow step 4b if you receive the FedEx label. Proceed to step 5.

1. Shipping Documents

a) Box Label

- Supplied with each Kit
- To be affixed to each box



b) Over-pack Label

- To be supplied by XPO.
- To be affixed to the outside of each pallet



c) Bill of Lading

- To be supplied by XPO.
- Print 2 copies: 1 for Dealer Records, 1 for LTL Driver



d) ERG Document

- To be supplied by XPO.
- To be provide by the Dealer to the LTL Driver for each shipment



5. Shipping Instructions – Prepare the Pallet

- Accumulate and palletize Kits
- Arrange Kits on Pallet as pictured here
 - 20 boxes per row/layer (5x4)
 - 10 rows/layers per pallet (200 boxes)
- Shrink-wrap Kits to Pallet
- Affix Over-pack Label on (1) side of Pallet (Not on Top)



6. Shipping Instructions – Schedule LTL Pickup

- Upon Accumulating 200 kits (1 Over-pack/Pallet) Minimum
 - Call XPO at 1-210-250-5079
 - If 200 Kits have not been accumulated in 30 days, please call XPO for direction
- Have the following information Available
 - Dealer #
 - Quantity of Over-packs/Pallets
 - Quantity of Passenger Inflator Kits on each Pallet
 - Email Address where shipping Documentation can be received

2. Packing Instructions

a) Confirm box is in acceptable condition. If a new box is needed, follow the New Box instructions located in Box B of this page.

b) Place the un-deployed air bag inflator in the "cradle" of the box insert.



3. Closure Instructions

a) Close the top box flap, per box closure instructions located on front panel of box.



7. Shipping Instructions – Ship

- Give 1 Copy of BOL and 1 Copy of ERG to Driver
- Retain 1 Copy of BOL for Dealership records and archive for 2 Years

8. Requesting a New Box / Shipping Labels

If a new box or replacement shipping labels are needed, please contact the representative listed below by phone or email to request replacement materials.

Primary Contact: Armando Gonzalez - Tel #: 210-250-5079

E-Mail: SCFieldaction.14305@xpo.com


To help expedite your request, please be prepared to provide the following information:

- Serial number on the original box
 - Replacement Box
 - Two Part Return Label
 - Bill of Lading
 - ERG Form
- Dealer Shipping Information
 - Contact name
 - Dealer Address
 - Phone Number




4a. Shipping Instructions - Label each Box

a) New Labels will begin shipping in each kit starting mid June, 2015



PARTS INFORMATION

DESCRIPTION	PART NUMBER	QUANTITY
INFLATOR – AIR BAG ASST (Air Bag Inflator)	98561-7999E	1 (If Needed)
MODULE KIT – SUB (Includes cushion, harness, air bag module mounting bolts, inflator securing nuts, and two (2) brackets)	K8515-EH19E	1 (If Needed)
Shorting Pin (Insulation Displacement Connector for 22-18 gauge wire) 	NAPA Item # 784566 Grainger Item # 4YT50 Or equivalent available from local auto supply	2 (If Needed)

NOTE:

- Make sure to return the removed (old / non-deployed) inflator in the box that the new inflator came in.
- Follow the return instructions provided on page 21.

EXPENSE CODE

EXPENSE CODE	DESCRIPTION	MAX AMOUNT
041	Shorting Pin (Insulation Displacement Connector for 22-18 gauge wire)	\$1.00

CLAIMS INFORMATION

Submit a “CM” line claim using the following claims coding:

CAMPAIGN (“CM”) ID	DESCRIPTION	OP CODE	FRT
PC908	Inspect Air Bag Inflator (OK Condition – Do Not Replace)	PC9080	0.3
	Inspect Air Bag Inflator, Remove and Replace Front Air Bag Module and Inflator	PC9081	2.7

AMENDMENT HISTORY

PUBLISHED DATE	REFERENCE	DESCRIPTION
August 15, 2022	ITB22-033	Original bulletin published