

AUTOCAR, LLC SAFETY RECALL DC-2201

April, 2022

ATTENTION:

Service Managers / Parts Managers.

SUBJECT:

Autocar, LLC has determined that a defect, which relates to motor vehicle safety, exists in 132, 2020-2022 model year Legend (DC) chassis. The grille bezel may be insufficiently attached, allowing it to detach from the vehicle.

SAFETY RECALL INFORMATION:

This document provides work instructions for the installation of additional grill bezel fasteners.

VEHICLES AFFECTED:

There are 132, 2020-2022 model year Legend (DC) chassis manufactured between May 16, 2019, and November 3, 2021, with non-sequential serial numbers between 230891 and 239016. To determine if a vehicle is affected by this Recall, log in to the Autocar Warranty Management System at www.autocartruck.com. From the main menu, select "View Recalls/ Service Programs" and look for the Autocar Recall number above. A spreadsheet file will be accessible with the VIN list of affected vehicles. Alternatively, to determine if a single vehicle is affected, select "VIN Profile" from the main menu in the Autocar Warranty Management System. In the "Chassis Number" field, enter the last 6 of the VIN. Once the VIN profile is displayed, scroll down to the "Recall/Service Program Information" section to determine if the Recall is open.

SERVICE RESPONSIBILITY:

Service sites must perform this Recall on affected vehicles at no charge to the owner regardless of vehicle mileage, age, or ownership. If a vehicle affected by this Recall is taken into or is currently in your vehicle inventory, or at your center for service, you must perform this Recall before the vehicle is sold or released to the owner.



AUTOCAR, LLC SAFETY RECALL DC-2201

April, 2022

REQUIRED PARTS:

- (1) S6721030K012 Service Kit
 - (6) A6200017-001 Plastic washers
 - (6) GE282025BS01 Nuts
 - (6) GE401525ES12 Bolts
 - (12) GE811625NS01 Flat washers

TO OBTAIN PARTS:

DO NOT submit a Solutions ticket. Verify that you have authorization from the customer to perform this work and send an e-mail to: warranty@autocartruck.com.

Include:

- **1.** VIN(s) (or) (last 6 digits of the VIN(s))
- 2. Attention To Name
- 3. Ship To Address

CLAIMS FOR REIMBURSEMENT:

Submit a claim for reimbursement in accordance with Autocar's Warranty Administration Manual with the following claim coding information:

CLAIM CODING INFORMATION:

Repair Number (Op Code)	Time Allowance (SRT)	Description
82310-0-01	1.00 HR	Grill Fasteners



AUTOCAR, LLC SAFETY RECALL DC-2201

April, 2022

SAFETY NOTICES:

🛕 WARNING

Allow the vehicle's engine and cooling system to cool to ambient temperature before performing the repair procedure. A hot engine or cooling assembly may cause burns or other personal injury.

M WARNING

To prevent eye injury, always wear eye protection when performing vehicle maintenance, service or inspection.

A WARNING

Before working on a vehicle, set the parking brake, place the transmission in neutral and block the wheels. Failure to do so can result in unexpected vehicle movement and can cause serious personal injury or death.



AUTOCAR, LLC SAFETY RECALL DC-2201

April, 2022

Working on CNG/LNG Trucks

SAFETY INSTRUCTIONS

If you store or dispense Compressed Natural Gas (CNG) or Liquefied Natural Gas (LNG), or if you work on CNG or LNG trucks, your location must be fully compliant with applicable codes, regulations and standards, including National Fire Protection Associate (NFPA) codes, Society of Automotive Engineers (SAE) standards, American National Standards Institute (ANSI) Natural Gas Vehicle (NGV) standards, the United States Code of Federal Regulations (CFR) and your state and local fire and other applicable codes (including, for example, the California Code of Regulations and the Texas Administrative Code).

Contact your local fire department for guidance and additional compliance information.

Technicians working on Autocar trucks with CNG or LNG engines must be trained in the proper repair of CNG and LNG trucks and engines and the safe storage and dispensing of CNG and LNG.

Working on CNG Fuel Systems



WARNING

CNG fuel systems include a high pressure (3600 psi) system for fuel storage and a low pressure system (125 psi) for consumption by the engine. Understanding the characteristics of CNG and how the fuel system works will prevent injury and damage to persons and property.

Attempting to operate or maintain any CNG fuel system without proper training is dangerous. Complete training and consult instructional bulletins from the CNG system suppliers, such as Agility Fuel Systems' Field Service Bulletin, Safely Working on CNG Fuel Systems.

Welding and Hot Work Near CNG and LNG Trucks



WARNING

Welding, grinding, and other "hot work" can be safely performed on or near a CNG or LNG vehicle, but certain precautions must be followed. Understand and perform the necessary precautions provided by the CNG system suppliers, such as Agility Fuel Systems' Field Service Bulletin, Welding and Hot Work Precautions Near CNG and LNG Vehicles.



AUTOCAR, LLC SAFETY RECALL DC-2201

April, 2022

CNG Cylinders



CNG fuel containers must meet Federal Motor Vehicle Safety Standard (FMVSS) 304 (Compressed Natural Gas Fuel Container Integrity) and/or ANSI/CSANGV2 (Basic Requirements for Compressed Natural Gas Vehicle Fuel Containers). Both standards specify a detailed visual examination every three years.

Truck owners are required to complete all necessary inspections, in accordance with the applicable standards and other resources, such as the Clean Vehicle Education Foundation and NGVAmerica's Compressed Natural Gas (CNG) Container Visual Inspection Advisory.

FMVSS 304 also requires that cylinders not be used after the end of life (EOL) date provided on the tank label. The EOL date is also displayed in the engine compartment and at the fueling connection of each truck. If there are any question as to proper decommissioning of a cylinder, contact the manufacturer, whose name and address is also required to be on the label.

CNG Fuel Container Pressure Relief Devices (PRDs)

MARNING

PRDs must be properly maintained and positioned for safe operation of a CNG fuel system. Missing vent caps can allow moisture into PRDs and vent lines, which can freeze and damage these safety components. Debris which clogs the PRDs and/or vent lines can prevent proper function.

PRDs must be positioned to vent upward, not outward, from a vehicle.

Ensure that every truck owner completes periodic inspections of the PRDs and vent lines and systems, in accordance with guidance provided by the system component suppliers.

Alert First Responders to CNG and LNG

M DANGER

In the event of a fire or other emergency, alert first responders to the presence and location of CNG fuel systems, tanks and dispensers. Ensure that emergency personnel are aware of proper precautions, such as those provided in Agility's *First Responder Guide: CNG and LNG Vehicle Fuel Systems*.

SAFETY RECALL BULLETIN

NHTSA RECALL 22V079

AUTOCAR, LLC SAFETY RECALL DC-2201



April, 2022

LOCKOUT/TAGOUT PROCEDURES:

A CAUTION

Before entering the vehicle or vehicle body, read and follow OSHA regulations concerning entry and working in "CONFINED SPACE" OSHA 1910.146 and "LOCKOUT/TAGOUT" OSHA 1910.147. Follow OSHA regulations while performing any work on the vehicle. The vehicle must be disabled by the following steps before performing any work on the vehicle:

- 1. Place the transmission in NEUTRAL.
- 2. Set the parking brake.
- 3. Shut the engine OFF.
- 4. Lock cab doors, keep the key in your pocket. Block the wheels before entering the body or performing any work on the vehicle.
- 5. Turn the battery disconnect switch OFF, if equipped.
- 6. Completely drain the air from the primary/A system and secondary/B system by opening the drain valves on the air tanks themselves or by using the drain manifold if supplied. When draining the air tanks, do not look into the area where air is draining. Dirt or sludge particles may be expelled in the air stream and can cause eye injury.
- Place magnetic "DANGER" signs on both cab doors before entering the body or performing any work on the vehicle.
- 8. Take proper precautions before working under the vehicle. Use ramps approved for the weight of your vehicle, or use floor jacks and stands. Never work under a vehicle supported by jacks alone. Always use jack stands to support the vehicle.



AUTOCAR, LLC SAFETY RECALL DC-2201

April, 2022

Grille Bezel Installation

- 1. Follow all lockout/tagout procedures and verify the battery disconnect switch is in the "OFF" position. If the unit is not equipped with a battery disconnect switch, disconnect the battery cables beginning with the negative cables, followed by the positive cables.
- 2. Unlatch and open the hood.



Due to the danger of sustaining personal injury and/or damage to the vehicle, never attempt to raise the hood outdoors under extremely windy conditions. The strong wind conditions could force the hood beyond the normal limits of its travel.

A WARNING

Allow the vehicle's engine and cooling system to cool to ambient temperature before performing the repair procedure. A hot engine or cooling assembly may cause burns or other personal injury.

SAFETY RECALL BULLETIN

NHTSA RECALL 22V079





April, 2022

3. Working from inside the raised hood remove (12) fasteners and set aside for reinstallation (see Figure 1).




Figure 1



AUTOCAR, LLC SAFETY RECALL DC-2201

April, 2022

4. Remove the grill from the hood and using a 1/4" drill bit, drill six holes in the grille starting at the bottom of the grille measure up 13" for the first hole. Then measure 7 3/4" up from the first hole to the second hole. From the second hole, measure another 7 3/4" for the third hole. Repeat this process for the opposite side of grille until all six holes have been drilled (see Figure 2).




Figure 2

SAFETY RECALL BULLETIN

NHTSA RECALL 22V079

AUTOCAR, LLC SAFETY RECALL DC-2201



April, 2022

5. In each of the previously drilled 1/4" holes install (1) GE401525ES12 bolt, (2) GE811625NS01 flat washers, (1) A6200017-001 plastic washer, and (1) GE282025BS01 nut. Tighten to 79 lbs.-in of torque (see Figure 3).




Figure 3

- 6. Reinstall the grille using the fasteners that were set aside in step 3.
- 7. Turn on the battery disconnect or re-connect the battery cables beginning with the positive cables followed by the negative cables.
- 8. Lower the hood.
- 9. The grille fastener installation is complete.

Note: If you have questions or concerns regarding this recall, please contact Autocar Technical Support at 888-218-3611.