

LEVELING AND STABILIZATION

Purpose

This document outlines the procedures to install footpads on Lippert Gen I, Gen II, and Titan hydraulic jacks.

Safety

Read and understand all instructions before installing or operating this product. Adhere to all safety labels.

⚠ WARNING

The RV must be supported according to the manufacturer's recommendations. Failure to do so may result in death or serious personal injury.

Resources Required

- Loctite™ 263 High Strength Thread Locker (Red)
- 1/2" Pneumatic or cordless impact wrench
- 15/16" Socket

Procedures

1. Apply Loctite™ 263 High Strength Thread Locker (Red) to the threads of the footpad bolt.

NOTE: Orient the bushing so the collar is facing upwards towards the bottom of the footpad (Fig. 1)

2. Insert bolt through the bushing, and footpad and thread bolt into bottom of jack (Fig. 2).
3. Tighten bolt using 1/2" impact wrench. Allow the impact to continue "clutching" for 2-3 seconds to achieve 45-50 ft-lbs. (61-68 Nm) of torque.

