

Safety Recall Notice Service Bulletin 508949 Rev. B

July 2019



631 West 11th Street • P.O. Box 310 • Winamac, IN 46996

(574) 946-4139 • 1-800-THE-LIFT • www.braunability.com

NHTSA Recall #: 19V546

Seat Solenoid Timer Installation Kit 508947KS

Applicable for Ford MXV With Flip n Go Seat
Shipped Before June 10, 2019



Warranty and Claim Topics: Recall / 19FXISS /
Repair

This service bulletin details installation of the
solenoid timer harness assembly.

Read instructions before beginning.

Passenger Side Seat Shown. Driver Side Seat is
Mirror Image.


Labor Time: 1 Hour




1. Tilt seat forward. See Photo A.

2. Inspect seat solenoid wiring for damage, wear, or
any abnormal condition. See Photos B and C.

If condition above is observed, contact Vehicle
Aftersales at 1-877-272-8633, Option 3.



MXV Solenoid Timer Installation Instruction 508949 Rev. B



Existing Hole




9/32" Hole

3. Locate existing hole shown in Photo D.




4. Drill a 9/32" approximately 1/2" from existing hole as shown in Photo E.


5. Secure solenoid timer harness assembly to underside of seat using hole drilled in Step 4 and screw included in kit. See Photos F and G.



MXV Solenoid Timer Installation Instruction 508949 Rev. B



Cable Tie



6. Remove cable tie, shown in Photo H, securing solenoid wires to underside of seat.

7. Connect solenoid timer assembly in-line as shown in Photo I.

8. Secure harness to underside of seat using cable tie included in kit. Refer to Photo H.

9. Connect relay, included in kit, to solenoid timer assembly. See Photos J and K.

10. Test for proper operation.

11. Repeat procedure on front seat on opposite side of vehicle.



Relay
BraunAbility Part
Number: 30907

