

RECALL 21V830. 2021-645 REMEDY INSTRUCTIONS



Make(s): XLR TOY HAULERS
Model(s): XLF301LRLE-79 & XLF335LRLE-79
Model Year(s): 2021 - 2022

Concern:
MANUFACTURING FORGOT TO INSTALL
A DIVIDER PANEL TO PROTECT THE
FURNACE FROM THE CARGO STORAGE
COMPARTMENT.

Repair Code: RC-024-03-00-004112
Allotted Time: .50 HRS.
Inspection Code: RC-024-03-00-004111
Allotted Time: .10 HRS.
Photo(s) Required: YES
Prior Authorization Required: YES
Part(s) Kit Number: 791432
Part(s) Return: N/A

Disconnect the vehicles' battery Positive and Negative, disconnect any House battery(s) Positive and Negative, if equipped with a generator ensure it is off and lastly, ensure the vehicle is disconnected from shore power. Block any tires/wheels to prevent the vehicle from rolling. Failure to do so may result in electrocution, fire or other personal injury, property damage and/or death.

INSPECTION:

STEP 1: OPEN THE DRIVERS SIDE PASS-THROUGH STORAGE COMPARTMENT DOOR;

STEP 2: LOCATE THE FURNACE ON THE RIGHT HAND SIDE OF THE COMPARTMENT;

STEP 3: IF THE FURNACE HAS A PANEL SEPARATING THE FURNACE FROM THE CARGO AREA, CLAIM THE INSPECTION CODE ONLY, CLEARING THE VEHICLE FROM THE RECALL.

REMEDY:

STEP 1: IF THE PANEL IS MISSING:

- MEASURE FROM THE MAIN FLOOR DIRECTLY UP TO THE BOTTOM OF THE BATH DECK FLOOR;
- MEASURE FROM THE INSIDE OF THE SIDEWALL INBOARD UNTIL THE MEASUREMENT IS SAFELY BEHIND THE FURNACE AND ANY WIRING, LPG LINES, WATER LINES, AND DUCTING;
- MEASURE FROM THE REAR OF THE BATH DECK (FROM THE FURNACE TO THE WALL REARWARD WALL OF THE BATH DECK);
- RECORD THESE DIMENSIONS, TWO PANELS WILL NEED TO BE CUT
 - THE FIRST PANEL IS GOING TO BE INSTALLED PERPENDICULAR FROM THE INSIDE OF THE SIDEWALL, JUST REARWARD OF THE BAGGAGE DOOR AND FORWARD OF THE FURNACE
 - THE SECOND PANEL IS GOING TO BE INSTALLED PARALLEL WITH THE VEHICLE. THIS PANEL IS TO BE LOCATED BEHIND THE FURNACE. THIS PANEL WILL MEET THE REAR OF THE BATH DECK WALL AND MAKE CONTACT WITH THE FIRST PANEL.
 - THESE PANELS WILL ISOLATE THE FURNACE FROM THE CARGO AREA.

STEP 2: THE FIRST PANEL THAT WILL BE PERPENDICULAR WILL NEED A CLEAT ASSEMBLED TO IT ACROSS THE LENGTH OF THE "BOTTOM" AND THE LENGTH OF THE "TOP" AND ANOTHER CLEAT VERTICALLY TO SECURE IT TO THE SIDEWALL;

STEP 3: THE SECOND PANEL THAT WILL BE PARALLEL WILL NEED A CLEAT ASSEMBLED TO IT ACROSS THE LENGTH OF THE "BOTTOM" AND THE LENGTH OF THE "TOP" AND ANOTHER CLEAT VERTICALLY TO SECURE IT TO THE BATH DECK WALL;

STEP 4: USING 1 ½" SCREWS, ATTACH THE PANELS INTO THE CARGO AREA, ISOLATING THE FURNACE FROM THE AREA AND PROTECTING IT;

STEP 5: CLAIM THE REPAIR CODE.

