Mazda North American Operations Irvine, CA 92618-2922



REFERENCE NO: RF-16-04 DATE: 5/27/2016

# SUBJECT: 2016 MAZDA3 (MEXICO BUILT) – CHANGE IN A-PILLAR CLIP (SERVICE PART D09W-68-162) FOR ACCESSORY INSTALLATION

There was a change in the A-pillar on the 2016 Mazda3 (Mexico built only), and some accessories are impacted by this. When installing one of the applicable accessory parts to the applicable vehicles, discard the existing A-Pillar Clip (Color: Black) inside the kit(s), and use a service part A-Pillar Clip (Color: White, PN: D09W-68-162) in its place. The Black clip cannot be installed properly on the A-pillar trim.

NOTE: The white A-pillar clip is not included in the accessory kit(s) and must be obtained separately.

#### **Applicable Model(s)/VINs:**

Model: Mazda3 (Mexico built only)

Production Plant: Salamanca

Built After 4/30/2016

#### VINs equal to and higher than 3MZBM1T72GM303197

- BM = Mazda3
- M = Mexico

NOTE: Japan Built Mazda3s are not affected and do not require the action above.

#### **Applicable Accessory Parts:**

0000-8C-L45 Mirror Kit with Compass

0000-8C-L14 Individual Parts Kit with Compass

0000-8C-L46 Mirror Kit with Compass and Homelink

0000-8C-L15 Individual Parts Kit with Compass and Homelink

0000-8F-L57 MMS Install Kit

BHP1-V7-050 Interior Lighting Kit









PN# D09W-68-162 ( Color: WHITE )

### USE

#### **Installation Tip:**

## USE THE SAME COLOR A-PILLAR CLIP AS THE ONE PREVIOUSLY

REMOVED. After removing the A-pillar trim, see what color the A-pillar clip is. If the A-pillar clip is white, then replace it with a new white clip. If the A-pillar clip is black, replace it with the black clip in the accessory kit.

	BEFORE	AFTER
Model / VIN(s)	Mexico Built Mazda3 / Before 3MZBM1T72GM303197	Mexico Built Mazda3 / Beginning with 3MZBM1T72GM303197 and on
A-Pillar Clip	PN# D651-68-162 (Color: BLACK)	PN# D09W-68-162 ( Color: WHITE )
How to install A- pillar clip	D651-68162	D09W-68162