


Solution K30290415 Thursday, August 29, 2019 9:21:30 PM CEST

** SOLUTION **


Title	Volvo Chassis - Diesel Exhaust Fluid (DEF) Access Door Installation Instructions	
Volvo Models		
Volvo Model	VN, VNL, VNR, VNX, VAH, VHD	
** SOLUTION **		
Cause An improperly installed DEF access door may allow the door to come open do vehicle operation.		
Solution	DEF Access Door Installation	

DEF Access Door Installation


1. Install two (2) spring nuts (PN 994944) onto the tabs on the backside of the DEF door panel (PN 84733671).




2. Slide and snap the DEF door hinge assembly (PN 84733141) into the snap features on backside of the DEF door panel (PN 84733671).




3. Install two (2) bolts (PN 996062) onto the spring nuts previously installed on DEF door panel.




4. Install the complete DEF door assembly onto the front chassis fairing assembly by using the magnet locator to correctly position the door assembly.




5. Install three (3) bolts (PN 995525) with three (3) washers (PN 994861) to secure the complete DEF door assembly in position.



Check for proper Fit and Function





Solution visibility	Dealer distribution		
Function(s)/component(s) affected			
Function affected	Body and Trim		
Function Group			
Function Group	891 exterior equipment		
Customer effect			

Visual appearance	loose, part lost/missing function	
Conditions		
Other conditions	after a workshop procedure on the vehicle	
Administration		
Author	UT0783V	
Dealer ID	UT0783V	
Last modified by	A241298	
Creation date	06-08-2019 17:08	
Date of last update	14-08-2019 14:08	
Review date	10-02-2020 00:02	
Status	Published	