

# WORK DESCRIPTION FOR FIELD MEASURE

## Check ashtray inserts and enclose as aftermarket measure if necessary

Model 223 with code 301

- i** • Code 301 corresponds to ashtray inserts in the front and rear in stowage compartments, as well as the rear cigarette lighter.

### Check/test procedure

1. Check whether two ashtray inserts are present in the vehicle.

**i** There must be **two** ashtray inserts present!

**i** It is possible that **no** or only **one** ashtray insert is present!

**i** At the factory, the two ashtray inserts are stored in an accessories bag in the trunk.

**i** The ashtray inserts may also be found in the vehicle interior. The ashtray inserts might be stored in the cup holders of the front and rear door trims on the left and right or in the cup holder at the front of the center console!

- a. If the ashtray inserts are **not** present or there is an **incorrect** quantity:  
Carry out **work procedure**.
- b. If the ashtray inserts are **present**: **End the measure**.

### Work procedure

1. Enclose ashtray inserts as an aftermarket measure.

**i** The test result determines whether one or two ashtray inserts must be enclosed as an aftermarket measure.

### Parts

Quantity	Designation	Part no.
As required	ASHTRAY	A 222 810 01 30 9J01

**i** Small parts such as screws/bolts, lock nuts, sealing rings, cable ties, fluids, sealant, etc. are not listed in the parts list. The required small parts are taken into account in the budgeting.

### Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-0341	Check ashtray inserts	0.1 h	81 920 08
02-0342	Enclose ashtray inserts as an aftermarket measure (after check)	0.1 h	81 920 08

Mercedes-Benz  
Global Service & Parts