



VEHICLE CONTROL MODULE REPROGRAMMING

When reprogramming a control module, always use the GR-8 battery management system Power Supply Mode. If not used, the control module reprogramming may fail due to a weak vehicle battery.

The GR-8 battery management system Power Supply Mode prevents the vehicle battery from being discharged. This allows the IDS to reprogram a control module without interference from a weak or undercharged vehicle battery.

Note: Control Module damage may occur if the GR-8 battery management system Power Supply Mode is not used.



GR-8 Battery Management System

An editorial board comprised of MNAO service staff members generates, collects, and verifies information for this publication. © 2016 Mazda Motor of America, Inc.

To contribute repair tip ideas, send an e-mail to mlips@mazdausa.com or fax to (949) 442-6599. If we select your repair tip, you will receive \$50 value in Reward Performance by Mazda (RPM) points for your efforts. All contributions become property of MNAO, which assumes permission to publish them without further consideration.