

SAFETY RECALL 14S08 – 2010-2014 MODEL YEAR TAURUS LICENSE PLATE LAMP ASSEMBLY INSPECTION

LICENSE PLATE LAMP ASSEMBLY VISUAL INSPECTION

With the head lamps turned off, visually inspect each license plate lamp assembly for the following:



1. Visible cracks in exposed portions of the lens and housing
2. Visible corrosion behind the clear lens



No visible cracks or corrosion

If cracks or corrosion are evident, please contact your dealer and request a service appointment without delay.

If neither cracks nor corrosion are evident, contact your dealer to schedule a service appointment for the end of September, 2014 when parts are anticipated to be available.

Note: *Vehicles with license plate lamp assemblies free of cracks or corrosion should be reinspected weekly until the repair is completed.*

CHECKING LICENSE PLATE LAMP OPERATION

Occasionally, license plate lamp bulbs burn out and must be replaced. If the license plate lamp assemblies pass inspection, but one or both lamps do not illuminate with the head lamps turned on, refer to your Owner's Manual for more information.