

# Bighorn Trey Ceiling Recall Repair Instructions

## Tools / Hardware needed:

- a. Drill with 3/8" Drill Bit.
- b. Screw Gun with #2 Square Bit.
- c. Six - 4" Screws
- d. Six Wood Buttons (Color based on trailer décor)



- 1) Find center of front and rear angled cove moldings and mark locations.



# Bighorn Trey Ceiling Recall Repair Instructions

- 2) Find center of each side angled cove moldings.  
Measure forward and back 6" from center and mark locations.



- 3) Drill 3/8" holes in flat area of angled cove moldings.  
(Use drop cloth or container to catch wood shavings)





# Bighorn Trey Ceiling Recall Repair Instructions

- 4) Install 4" screw into each of the 6 holes to secure tray ceiling to structure.



- 5) Glue wood buttons into the drilled 3/8" holes.

