

MODEL 215.373 /374 /375 /376 /378 /379
MODEL 220.025 /026 /028 /063 /065 /067 /070 /073 /074 /075 /083 /084 /087 /125 /126 /128 /163 /165 /167 /170 /173 /174 /175 /176 /178 /179 /183 /184 /187 /875 /878
MODEL 230 up to model year 2008

Shown on model 220

- A1p13 Multifunction display (model 215, 220)
- A1p13 Left multifunction display (model 230)
- A1r1 Instrument and search illumination brightness control (model 215)
- A1r1 Instrument illumination brightness control and reset button (model 230)
- A1s1 Reset button (model 220)
- S110s1 Scroll forward/back button
- S110s3 System selection button



P54.30-6878-06

Modification notes

8.9.08	Close trunk lid, engine hood and doors, added	Step 1	
--------	---	--------	--

	Adjust		
1	Close trunk lid, engine hood and doors	Vehicles with code (491) USA version or code (494) USA version	
2	Switch on ignition		
3	Press system selection button (S110s3) repeatedly until the total kilometer reading is shown in the multifunction display (A1p13)		
4	Press the scroll forward/back button (S110s1) repeatedly until the service symbol is shown in the multifunction display (A1p13)		
5	Keep the reset button (A1s1) or brightness control (A1r1) pressed for 3 seconds	<p>i In the multifunction display (A1p13) appears the inquiry "DO YOU WANT TO RESET THE SERVICE INTERVAL? CONFIRM WITH R BUTTON".</p> <p>i R-BUTTON = Reset button (A1s1) or brightness control (A1r1).</p>	
6	Press the reset button (A1s1) or brightness control (A1r1) again		
7	Switch off ignition		