# PREVOST

# Instruction Sheet

IS-18910

### **DIESEL FLAP INSTALLATION**

This instruction sheet shows how to install a flap over the diesel filling cap.

### **EFFECTIVITY: ALL H3 AND X3 MODELS WITH DEF TANK**

Model	VIN PRODUCTION OF THE PROPERTY
All H3 models  Model Years : from 2011	From <u><b>B-1721</b></u>
All X3 models Model Years : from 2011	From <u><b>B-5002</b></u>

MODEL	KIT TO ORDER	FLAP ASSEMBLY
H3 MODELS	IS18910	STORING CO.
X3 MODELS WITH LOCK	IS18910-2	
X3 MODELS WITHOUT LOCK	IS18910-3	

# **H3 MODELS FLAP INSTALLATION**




FIGURE 1: H3 MODELS FLAP INSTALLATION

Order kit # IS18910 that contains the following parts:

Part No.	Description	
030109	FLAP ASSEMBLY (H3 MODELS)	1
IS-18910	INSTRUCTION SHEET	1
FI-18910	FEUILLE D'INSTRUCTION	1

Writer: ML <QF7720959 rev 5>

# X3 MODELS WITH LOCK FLAP INSTALLATION




FIGURE 2: X3 MODELS WITH LOCK MODELS FLAP INSTALLATION

Order kit # IS18910-2 that contains the following parts:

Part No.	Description	
033219	FLAP ASSEMBLY X3 MODELS (WITH LOCK)	1
IS-18910	INSTRUCTION SHEET	1
FI-18910	FEUILLE D'INSTRUCTION	1

Writer: ML <QF7720959 rev 5>

# 0 USE **EXISTING SCREWS**

# X3 MODELS WITHOUT LOCK FLAP INSTALLATION

FIGURE 3: X3 MODELS WITHOUT LOCK FLAP INSTALLATION

Order kit # IS18910-3 that contains the following parts:

Part No.	Description	
033215	FLAP ASSEMBLY X3 MODELS (WITHOUT LOCK)	1
IS-18910	INSTRUCTION SHEET	1
FI-18910	FEUILLE D'INSTRUCTION	1

### **PARTS / WASTE DISPOSAL**

Discard waste according to applicable environmental regulations (Municipal/State[Prov.]/ Federal)

Writer: ML <QF7720959 rev 5>