

WORK DESCRIPTION FOR FIELD MEASURE

Code: 20P5492209

Version: 2.0

Update M67, M67/1, M67/2 and M67/3 control unit software

Model 167 with special equipment 489 and 490

- i** • Code 489 corresponds to "AIRMATIC DC/SEMI-ACTIVE AIR SUSPENSION"
- Code 490 corresponds to "ELECTROHYDRAULIC SUSPENSION"
- i** • Ensure use of **XENTRY/DAS version** BD/DVD (**06/2020**) or higher.
- Before starting the work procedure, install all the **add-ons that are updated daily** in **XENTRY/DAS**.
- Please make sure to follow the operation steps exactly as described in XENTRY/DAS.
- Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
- If XENTRY/DAS is already connected to the vehicle, start with **operation step 2**.
- i** If two or more software updates or SCN codings are performed during one workshop visit, the operation items 02-4762 and 02-5058 may only be invoiced **once for each workshop order!**

Work procedure

1. Connect XENTRY/DAS.
2. Update **M67, M67/1, M67/2 and M67/3** control unit software.
 - i** To do this, select menu item "Quick test view – **M67, M67/1, M67/2 and M67/3**- Adaptations – Control unit update – Update of control unit software".
 - i** Then follow the user guidance in XENTRY/DAS.
3. Disconnect XENTRY/DAS.

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9334*	Update M67 control unit software (with XENTRY/DAS connected)	0.1 h	54 922 09
02-9334*	Update M67/1 control unit software (with XENTRY/DAS connected)	0.1 h	54 922 09
02-9334*	Update M67/2 control unit software (with XENTRY/DAS connected)	0.1 h	54 922 09
02-9334*	Update M67/3 control unit software (with XENTRY/DAS connected)	0.1 h	54 922 09
02-4762**	Connect/disconnect vehicle diagnosis system (XENTRY/DAS)	0.1 h	54 922 09
02-5058**	Connect/disconnect starter battery charger (with XENTRY/DAS connected)	0.1 h	54 922 09

* Please manually enter the affected control unit with code and accounting number in the workshop order as per the work instructions.

** Operation item may only be invoiced once for each workshop order!

