

WORK DESCRIPTION FOR FIELD MEASURE

Code: 21P5891115

Version: 2.0

Update Digital Operator's Manual and enclose printed operator's manual, replace if necessary
Model 167

i The codes correspond to:

- 549 - CONNECT 20 HIGH (NTG6).
- 548 - CONNECT 20 MID (NTG6).
- ME05 - PLUG-IN HYBRID VEHICLE.
- ME10 - HYBRID VEHICLE.

Work procedure A:

Update Digital Operator's Manual with parts scope

Page 2/3

Work procedure B:

Enclose printed operator's manual with parts scope as an aftermarket measure, replace if necessary
Page 3/3

Operation text and flat rate

Page 3/3

Work procedure A

i Update Digital Operator's Manual.

- i**
- Ensure use of **XENTRY Diagnosis version** BD/DVD (**09/2020**) or higher.
 - Before starting the work procedure, install all the **add-ons that are updated daily** in **XENTRY Diagnosis**.
 - Make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
 - Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
 - If XENTRY Diagnosis is already connected to the vehicle, start with **operation step 2**.

i If two or more software updates or SCN codings are performed during one workshop visit, the operation items 02-4762 and 02-5058 may only be invoiced **once for each workshop order!**

1. Connect XENTRY Diagnosis.

2. Update COMAND Online control unit software.

i To do this, select menu item "Quick test view – COMAND Online - Adaptations – Initial control unit startup – Initial startup of the already installed control unit".

i Then follow the user guidance in XENTRY Diagnosis.

3. Disconnect XENTRY Diagnosis.

4. Carry out **work procedure B**.

Parts scope – Digital Operator's Manual

Quantity	Designation	Part no.
1	Digital Operator's Manual	*

* **The Digital Operator's Manuals for the vehicle identification number and equipment variant must be procured via the parts process in the Xentry Portal.**

Work procedure B

i Enclose printed operator's manual as an aftermarket measure, replace if necessary.

1. Check whether the printed operator's manual is in the vehicle document wallet and whether it is the correct version, enclose if necessary.

i If a printed operator's manual is **not present**, the printed operator's manual must be placed in the vehicle document wallet as an aftermarket measure.

i If there is a printed operator's manual, compare it with the parts table and replace if necessary.

Parts scope – Printed operator's manual

Quantity	Part no.	Designation	Language	Code
As required (1)*	A 167 584 16 11	OPERATOR'S MANUAL A-HIGH US ENGL USA CAN A-2021	English USA	549 + 12B
As required (1)*	A 167 584 05 11	OPERATOR'S MANUAL A-MID US ENGL USA CAN A-2021	English USA	548 + 12B
As required (1)*	A 167 584 40 11	SUPPLEMENT HYBRID USA CAN A-2021	English USA	(ME05/ME10) + 12B

* The operator's manuals must be procured via the parts process in the Xentry Portal.

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9445	Update Digital Operator's Manual (with XENTRY Diagnosis connected)	0.1 h	58 911 15
02-9471 *	Check operator's manual, enclose if necessary	0.1 h	58 911 15
02-4762**	Connect/disconnect vehicle diagnosis system (XENTRY Diagnosis)	0.1 h	58 911 15
02-5058**	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	58 911 15

* The operation item contains 3 operator's manuals; check, enclose if necessary. The operation item is thus to be used with the respective frequency depending on the vehicle equipment! In the case of 1 to 3 operator's manuals, the operation item must be used once. In the case of 4 to 6 operator's manuals, the operation item must be used twice. In the case of 7 to 9 operator's manuals, the operation item must be used three times.

** Operation item may only be invoiced once for each workshop order!

Mercedes-Benz
Global Service & Parts