

WORK DESCRIPTION FOR FIELD MEASURE

Code: 26P5891326

Version: 2.0

Update Digital Operator's Manual

Model 118, 177, 243, and 247

- i** • Always use the **latest** XENTRY Diagnosis software release with all available add-ons.
 - Make sure to follow the operation steps exactly as described in XENTRY Diagnosis!
 - Use a battery charger to ensure sufficient power supply is available for the vehicle's **on-board electrical system battery** (greater than 12.5 V).
 - If XENTRY Diagnosis is already connected to the vehicle, start with **Work Procedure Step 2**.
- i** If two or more software updates or SCN codings are performed during one workshop visit, operation items 02-4762 and 02-5058 must **only be invoiced once for each workshop order!**

Work Procedure

i Update Digital Operator's Manual.

1. Connect XENTRY Diagnosis.

2. Update Digital Operator's Manual.

i To do this, select menu item "Quick test view → **A26/17 - MBUX multimedia system (head unit)** → Adaptations → Control unit update → Update control unit software".

i Then follow the user guidance in XENTRY Diagnosis.

i The Digital Operator's Manuals are downloaded automatically via Retail Data Storage to XENTRY Diagnosis to match the affected vehicle.

3. Disconnect XENTRY Diagnosis.

Operation text and target time

Operation no.	Operation text	Target time	Accounting no./ damage code
02-9445	Update Digital Operator's Manual	0.1	58 913 26
02-4762*	Connect/disconnect diagnostic system (XENTRY Diagnosis)	0.1	58 913 26
02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1	58 913 26

* Operation item may be invoiced only once for each workshop Repair Order!

Mercedes-Benz