

WORK DESCRIPTION FOR FIELD MEASURE

Code: 26P5496831

Version: 2.0

Perform overall vehicle update

Model 174

-  • Always use the **latest** XENTRY Diagnosis software release with all available add-ons.
 - Make sure to follow the operation steps exactly as described in XENTRY Diagnosis!
 - Use a battery charger to ensure a sufficient power supply is available for the vehicle's **on-board electrical system battery** (greater than 12.5 V).
 - If XENTRY Diagnosis is already connected to the vehicle, start with work procedure **operation step 2**.
-  If, during one workshop, two or more software updates or SCN coding's are performed, operation items 02-4762 and 02-5058 may **only be invoiced once per workshop order!**

Work procedure:

1. Connect XENTRY Diagnosis.
2. Perform **overall vehicle update**.
 -  To do so, select menu item "General overview" → **Overall vehicle update**.
 -  Then follow the user guidance in XENTRY Diagnosis.
 -  Depending on which control units need to be updated along with it, **the update can take up to several hours to complete. The update will be completed automatically.**
3. Disconnect XENTRY Diagnosis.

Operation text and target time:

Operation no.	Operation text	Target time	Accounting no.
02-9334	Update control unit for A26/17 – MBUX head unit (with XENTRY Diagnosis connected)	0.1	54 968 31
02-4762**	Connect/disconnect diagnosis system (XENTRY Diagnosis)	0.1	54 968 31
02-5058**	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1	54 968 31

*The prescribed times are available in the relevant systems (e.g. XENTRY Operation Time).

** This operation item may only be invoiced once for each workshop order!