

WORK DESCRIPTION FOR FIELD MEASURE

Code: 21P5499730

Version: 2.0

Update left and right front door/rear door control unit software

Model 223

- i** • Ensure use of **XENTRY Diagnosis version** BD/DVD (**12/2020**) or higher.
- Before starting the work procedure, install the **current version of all add-ons** in **XENTRY Diagnosis**.
- Make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
- Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
- If XENTRY Diagnosis is already connected to the vehicle, start with **operation step 2**.
 - i** If two or more software updates or SCN codings are performed at one workshop visit, operation items 02-4762 and 02-5058 may be charged **only once per workshop order**.

Work procedure

1. Connect XENTRY Diagnosis.
2. Update left front door control unit software.
 - i** To do this, select menu item "Quick test view – N69/1 Left front door (DCU-LF) – Adaptations – Control unit update – Update of control unit software".
 - i** Then follow the user guidance in XENTRY Diagnosis.
3. Update right front door control unit software.
 - i** To do this, select menu item "Quick test view – N69/2 Right front door (DCU-RF) – Adaptations – Control unit update – Update of control unit software".
 - i** Then follow the user guidance in XENTRY Diagnosis.
4. Update left rear door control unit software.
 - i** To do this, select menu item "Quick test view – N69/3 Left rear door (DCU-LR) – Adaptations – Control unit update – Update of control unit software".
 - i** Then follow the user guidance in XENTRY Diagnosis.
5. Update right rear door control unit software.
 - i** To do this, select menu item "Quick test view – N69/4 Right rear door (DCU-RR) – Adaptations – Control unit update – Update of control unit software".
 - i** Then follow the user guidance in XENTRY Diagnosis.
6. Disconnect XENTRY Diagnosis.

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9334	Update left front door control unit software (with XENTRY Diagnosis connected)	0.1 h	54 997 30
02-9334	Update right front door control unit software (with XENTRY Diagnosis connected)	0.1 h	54 997 30
02-9334	Update left rear door control unit software (with XENTRY Diagnosis connected)	0.1 h	54 997 30
02-9334	Update right rear door control unit software (with XENTRY Diagnosis connected)	0.1 h	54 997 30
02-4762*	Connect/disconnect vehicle diagnosis system (XENTRY Diagnosis)	0.1 h	54 997 30
02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	54 997 30

* Invoice operation item only once for each workshop order.

Mercedes-Benz
Global Service & Parts