

WORK DESCRIPTION FOR FIELD MEASURE

Code: 22P5496206

Version: 2.0

Update driver display, front passenger display, and central display control unit software

Model 297 with code 535

i Code 535 corresponds to Connect 20 Premium (NTG7).

- i** • Ensure use of **XENTRY Diagnosis version 06/2022** or higher.
 - Before starting the work procedure, install the **current version of all add-ons** in **XENTRY Diagnosis**.
 - Make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
 - Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
 - If XENTRY Diagnosis is already connected to the vehicle, start with **operation step 2**.
- i** If two or more software updates or SCN codings are performed during one workshop visit, operation items 02-4762 and 02-5058 may be invoiced **only once for each workshop order**.

Work procedure

1. Connect XENTRY Diagnosis.
 2. Update the **instrument cluster** control unit software.
 - i** To do this, select menu item "Quick test view – **A40/18 driver display (IDP)** – Adaptations – Control unit update – Update of control unit software".
 - i** Then follow the user guidance in XENTRY Diagnosis.
 3. Update the **instrument cluster** control unit software.
 - i** To do this, select menu item "quick test view – **A40/26 front passenger display (DBF)** – Adaptations – Control unit update – Update of control unit software".
 - i** Then follow the user guidance in XENTRY Diagnosis.
 4. Update the **instrument cluster** control unit software.
 - i** To do this, select menu item "quick test view – **A40/8 central display (ZAN)** – Adaptations – Control unit update – Update of control unit software".
 - i** Then follow the user guidance in XENTRY Diagnosis.
 5. Disconnect XENTRY Diagnosis.
-

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9334	Update driver display control unit software (with XENTRY Diagnosis connected)	0.1 h	54 962 06
02-9334	Update front passenger display control unit software (with XENTRY Diagnosis connected)	0.1 h	54 962 06
02-9334	Update central display control unit software (with XENTRY Diagnosis connected)	0.1 h	54 962 06
02-4762*	Connect/disconnect diagnostic system (XENTRY Diagnosis)	0.1 h	54 962 06
02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	54 962 06

* Operation item may be invoiced only once for each workshop order!

Mercedes-Benz
Global Service & Parts