( ) gracenote.	to the Graceno
	F10 7" Naviga
	nre-recorded (

**INTRODUCTION:** 

This Service Information bulletin announces availability of an enhancement te database included in the vehicles listed above equipped with tion and 7" Display Audio head units. When the user plays a pre-recorded CD, Gracenote recognizes the disc then shows the artist and

track name information along with the album cover art on the head unit display (when available). This enhancement brings the currently installed database up to date with the most recent information available. This update does not affect any album art displayed when using SXM.

SERVICE BULLETIN

# **PRODUCTION CHANGE INFORMATION:**

Since the Gracenote database updates are ongoing, the latest version available is installed at vehicle production. A version Check procedure is supplied in the Service Procedure portion of this bulletin.

#### **PART INFORMATION:**

VERY IMPORTANT: The Gracenote software files are being supplied to Retailers through the existing Audio / Downloads link page on Subarunet at no charge.


\*\*Any charges to install the Gracenote enhancement files are not a matter for warranty and are strictly between the Retailer and the customer.

#### Continued...

Subaru Service Bulletins are intended for use by professional technicians ONLY. They are written to inform those technicians of conditions that may occur in some vehicles, or to provide information that could assist in the proper servicing of the vehicle. Properly trained technicians have the equipment, tools, safety instructions, and know-how to do the job correctly and safely. If a condition is described, DO NOT assume that this Service Bulletin applies to your vehicle, or that your vehicle will have that condition.

to our environment and in accordance with all

local, state and federal laws and regulations.



ATTENTION:	1				1	
GENERAL MANAGER		IMPORTANT - All Service Personnel				
PARTS MANAGER		Should Read and				
CLAIMS PERSONNEL		Initial in the boxes provided, right.				
SERVICE MANAGER		© 2017 Subaru o	f Ameri	ca, Inc.	All righ	ts res

2015-2016MY Impreza

2015-18MY Forester

2015-2017MY Crosstrek

Software Enhancement

2016-2018MY WRX and WRX STI

SUBJECT: Availability of "Gracenote® Media Database"

Models with Gen 2 and Gen 2.1 Fujitsu-Ten (F10) 7" Display Navigation and 7" Display Audio Units

**APPLICABILITY:** 2015-2017MY Legacy, Outback



QUALITY DRIVEN® SERVICE

### **MATERIALS REQUIRED:**

One empty 2GB, USB 2.0 (do **NOT** use USB 3.0) storage device (flash drive) will be needed to perform the procedure. The device should be dedicated to storing and transferring these updating files only. It should also be no more than 4GB in size and **MUST** contain a FAT32 file format before downloading the update files onto it.



# **SERVICE PROCEDURE / INFORMATION:**

**STEP 1:** Identify the model of the head unit.



**STEP 2:** Perform the Version Check procedure:



Press the **HOME** button and from the home screen, press **SETTINGS**.

From the SETTINGS screen, press GENERAL.

SETTINGS		≰×	
Screen off	General	Split screen	Display
Bluetooth	Telephone	<b>JJ</b> Audio	Vehicle customisation
-	-	-	

### From the General Settings Screen, press Gracenote<sup>®</sup> Database Update

The Gracenote<sup>®</sup> Database Update screen will display the Library Version and the Database Revision information. Use the Database Revision number to determine whether or not the unit is suitable for installation of the new files. Compare the number to the Target Version number in the table below.

- If it is **equal to or higher** than the Target Version number in the table (12805), the unit has the most recent version installed and no further action is required.
- If it is **lower** than the Target Version number in the table (12805), the unit is suitable for



the enhancement. Proceed with the update procedure outlined below.


Model	Model Year	Туре	H/U Model ID#	Target Version
	2015	Navi	FB644US	
			FB664US	
		DA	FB644UM	
		DA	FB664UM	
		Navi	FB685US	
Legacy /	2016	INAVI	FB695US	
Outback	2010	DA	FB685UM	
		DA	FB695UM	
		Navi FB856US FB876US	FB856US	
	2017		l	
	2017	DA	FB856UM	<mark>12805</mark>
			FB876UM	
	2015	Navi	FM634US	
	2015	DA	FM664UM	
		Navi FM655UH FM675UH FM685UM	FM655UH	
Improza /	2016			
Impreza / Crosstrek	2010		FM685UM	
		DA	FM705UM	
	2017	Navi	FM666US	
			FM686US	
		DA	FM685UM	

**Navi** = Audio units with Navigation **DA** = Display Audio units (without navigation)

Model	Model Year	Туре	H/U Model ID#	Target Version
	2016	Navi	FF667US	
			FF687US	
		DA	FF667UM	
		DA	FF687UM	
		Navi	FF868US	
Forester	2017	INAVI	FF878US	
10163(6)	2017	DA	FF678UM	
			FF698UM	
	2018	Navi	FF629US	
			FF639US	<mark>12805</mark>
		DA	FF679UM	12000
			FF689UM	
	2016	Navi	FV631US	
		DA	FV651UM	
		Navi	FV624US	
WRX / WRX STI	2017	DA	FV662UM	
			FV672UM	
	2018 Na	Navi	FF673US	
			FV833UM	
		DA	FV843UM	

**STEP 3:** After performing the Version Check procedure, if determined the unit is suitable for updating and customer authorization has been obtained, the new files will need to be downloaded onto the flash drive. All the F10 update files are accessible for downloading from Subarunet under: Service Operations & Technical >> Forms/Downloads >> Downloads for Audio/Navi then clicking on the applicable hyperlink:

Click Here to Access the Downloads for Audio/Navigation Information on Subarunet



# **STEP 4:** Prepare the USB Memory (Flash Drive)


**VERY IMPORTANT:** Before attempting to download any data files, confirm the PC and flash drives you are using are not infected with any virus. The flash drives will need to be formatted for FAT32 following the steps below.

#### **USB Flash Drive Formatting Procedure:**


Google Chrome 0 Adobe Acrobat 9 Pro ۲ Install a flash drive into an available USB port • Documents D Adobe InDesign CS5 on your PC. Computer Adobe Photoshop CS5 ۲ Click Start (this is located in the lower left ٠ **Control Panel** corner of the desktop screen) then, in the WE Microsoft Office Word 2007 Search programs and files box, type **Devices and Printers** Adobe Illustrator CS5 "explorer". Default Programs 0 Microsoft Office FrontPage 2003 Help and Support Notepad Calculator Getting Started All Programs Shut down 🕨 Search programs and files Q E X Start Button


**NOTE:** On SDS Notebook you may also press the My Documents button on the GUI Home Screen.

• As you type the word "explorer", search results will start to appear. In the results, click on the "Windows **Explorer**" option under the **Programs** section.



• In the next window, choose the Computer section on the left. Locate "Removable Disk"






• When the "Format" dialog box appears, make sure that the option labeled "File System" is set to **FAT32** and the **Quick Format** box is checked as well. Then, click the **"Start"** button.

🖉 🗢 🕞 🗸 Comp	outer 🕨				▼ 4 <sub>7</sub>	Search Computer	Q
Organize 💌 Eject	Properties	System properties	Uninstall or change a program	Map network drive	Open Control Panel	₩ <b>=</b> ▼ 1	0
☆ Favorites ■ Desktop ▶ Downloads ₩ Recent Places		Disk Drives (1) Local Disk (C:) 236 GB free of 297 GB es with Removable S	itorage (3)				
🕽 Libraries 📄 Documents 🎝 Music		DVD RW Drive (D:)		trive (E:)	Removable Disk (F:) 25.6 GB free of 29.8 G	] B	
Pictures     Videos     Computer     Coal Disk (C:)     Removable Disk (     Network		rk Location (5)			Format Removable Disk (F;)           Capacity:           29.8 GB           File system           [FAT32 (Default)           Allocation unit size           16 kilobytes           Restore device defaults		
Removable Removable I	Disk (F:) Space Disk Space	e used: e free: 25.6 GB	Total size: 29.8 GB File system: FAT32		Volume label Format options Quick Format Create an MS-DOS startup d	sk Close	

• Click "OK" when the following window appears.




• The drive will start formatting and display this window when it is finished. Click "OK" to complete the process.




• Repeat the procedure above for the second flash drive

**STEP 5:** File Download Procedure:


After formatting of the flash drive is complete, the new file must be downloaded onto it. Download the new file to your PC from the Subarunet link. **NOTE:** The new file may contain 1 to 3 individual files. The screenshots below will take you through the steps required to get the new files onto the flash drive and ready to use. Update File sizes are quite large and depending on the speed capabilities of the computer, may take some time to complete the download. **PLEASE BE PATIENT!** 





Once the download is complete, you will need to locate the new file, unzip it and save the unzipped version to the USB flash drive. **NOTE:** If not already done, follow the procedure above for formatting (removing any existing files) from the flash drive.

- Plug the "clean" flash drive into the PC.
- Go to the Windows Start screen, select "Computer" (or click on My Documents if using the SDS Toughbook) and click on "Downloads".



Once the list of downloaded files opens, click on Date Modified which will arrange them by date and bring the newest to the top. Double-click on the new file, click on "Run", Click on "Browse" then select "Removable Disc" which will be the flash drive. Click "Unzip" to load the files onto the flash drive and when complete, insert the flash drive into the vehicle USB port.

# **IMPORTANT NOTES:**

- Do not change the file names after downloading them
- Do not save any other files onto the flash drive.

### **STEP 6:** Software Installation:

Subaru of America, Inc. (SOA) highly recommends connecting either the Subaru Midtronics DCA-8000 Dynamic Diagnostic Charging System or the Subaru Midtronics GR8-100 Diagnostic Battery Charger to the vehicle and utilizing the Power Supply Mode feature anytime a vehicle control module or head unit is being reprogrammed.

Once the Midtronics charger is connected to the vehicle, if the battery is fully charged, it takes less than three (3) minutes to boot-up the charger, select the Power Supply Mode, and have the battery voltage stabilized and ready for reprogramming.

### **NOTES:**

For instructions on using the power supply mode, reference the applicable User Manual for the Midtronics DCA-8000 Dynamic Diagnostic Charging System and the Midtronics GR8-1100 Diagnostic Battery Charger on STIS.

- Confirm all electrical loads such as lights, audio, HVAC, seat heaters, and rear defroster are all switched **OFF** before setting up the charger for Power Supply Mode.
- Select the correct battery type (Flooded, EFB, Gel, AGM or AGM Spiral).
- Input the CCA which matches the vehicle's battery. **NOTE:** OE and replacement batteries have different CCA ratings. Always confirm the battery's CCA rating before proceeding.
- If using a DCA-8000 Dynamic Diagnostic Charging System, set the power supply voltage to 13.5 volts.
- **DO NOT** connect the DST-i or SDI until the Power Supply mode function has completed its battery test mode and the Charging Voltage has dropped to and shows a steady 13.5 Volts on the display.
- Once Power Supply Mode reaches a steady 13.5 volts, connect the DST-i or SDI to the OBD connector and proceed with initiating the normal FlashWrite reprogramming process.
- Amperage will fluctuate based upon the vehicle's demand for power. **NOTE:** If the voltage rises beyond 14V while programming is in process, the procedure will abort. This can indicate a need to test or charge the vehicle battery before any further attempt at programming is made.

# VERY IMPORTANT:

This information is applicable to the Subaru Midtronics DCA-8000 Dynamic Diagnostic Charging System and the Subaru Midtronics GR8-1100 Diagnostic Battery Charger ONLY. It does not apply to any other brand / type of "generic" battery charger whatsoever. ONLY the DCA-8000 and the GR8-1100 and their Power Supply Mode feature have been tested and approved by SOA. **REMINDER:** If the DCA-8000 or GR8-1100 indicates the vehicle's battery must be charged, charge the battery fully before proceeding to reprogram the vehicle while using the Power Supply Mode.

**STEP 7:** Install the Database Update files

Return to the Gracenote Database Update screen by:

- Press the **HOME** button and from the home screen, press **SETTINGS**.
- From the SETTINGS screen, press GENERAL.
- From the General Settings screen, press Gracenote<sup>®</sup> Database Update
- From the Gracenote® Database Update screen press Update.
- Press Yes.

Gracenote® Database Update	<b>∢</b> ×	P	Gracenote® Database Updat	
Gracenote® Library Version:	5.6.2.3		Gracenotete Database Opca	
Gracenote® Database Revision:	7633			
Please select "Update" after inse Gracenote® database.	rting a USB flash di	rive with the	Gracenote® database update may Would you like to start the Gra	
Update	Update His	story		
			Yes	No
<b>V</b> <sup>E</sup>			1. E	

**NOTE:** If there is a problem with the USB drive or the files, after pressing **Update**, the message screen below will be displayed before the update begins.



In the event this screen is displayed:

- Press "OK", remove the flash drive and return to Step 4 above..
- Plug the flash drive back into the PC and re-format it.
- Download the files again from Subarunet and reload them onto the flash drive.
- Try to install the update again.

While the update is taking place, the screen below with a status bar will be displayed. **NOTE:** The update can take up to 30 minutes to complete.



When completed successfully, the screen shot below will be displayed.

Gracenote® Database Update	∢×
The Gracenote® database was successfully updated	to the following version.
Gracenote® Library Version:	5.6.2.3
Gracenote® Database Revision:	12805
ОК	
Portions of the content are under copyright© by Gra	cenote® or its providers.

### **IMPORTANT REMINDERS:**

- SOA strongly discourages the printing and/or local storage of service information as previously released information and electronic publications may be updated at any time.
- Always check for any open recalls or campaigns anytime a vehicle is in for servicing.
- Always refer to STIS for the latest service information before performing any repairs.