

# Quick Guide **CROSSTREK** 2019



Love. It's what makes a Subaru, a Subaru.

 **SUBARU**  
Confidence in Motion

© 2018 Subaru of America, Inc. All rights reserved.

Contents may not be reproduced in whole or in part without prior written permission of publisher. Specifications in this Guide are based on the latest product information available at the time of publication. Some images shown are for illustration purposes only. Some equipment shown in photography within this Guide is optional at extra cost. Specific options may be available only in combination with other options. Specific combinations of equipment or features may vary from time to time, and by geographic area. Subaru of America, Inc. reserves the right to change or discontinue at any time, without notice: Prices, colors, materials, equipment, accessories, specifications, models and packages, without incurring any obligation to make the same or similar changes on vehicles previously sold. Colors shown may vary due to reproduction and printing processes. Subaru of America, Inc. is not responsible for typographical errors.

Aha™ is a trademark of Harman International Industries, Inc. Alcantara® is a registered trademark of Alcantara S.p.A., and Alcantara is produced by the Toray Group. App Store® is a registered trademark of Apple, Inc. Apple® is a registered trademark of Apple, Inc. BBS® is a registered trademark of BBS Kraftfahrzeugtechnik, AG. Bluetooth® is a registered trademark of Bluetooth SIG, Inc. Brembo® is a registered trademark of Freni Brembo, S.p.A. GreenEdge® is a registered trademark of Harman International Industries, Inc. Harman Kardon® is a registered trademark of Harman International Industries, Inc. HD Radio® is a registered trademark of iBiquity Digital Corporation. HomeLink® is a registered trademark of Prince Corporation, a wholly owned subsidiary of Johnson Controls. iHeart® Radio is a registered trademark of iHeartMedia, Inc. iPod® is a registered trademark of Apple, Inc. iTunes® is a registered trademark of Apple, Inc. Metal-Matrix Diaphragm (MMD®) is a registered trademark of Harman International Industries, Inc. MirrorLink™ is a trademark of Car Connectivity Consortium, LLC. Pandora® is a registered trademark of Pandora Media, Inc. Siri® is a registered trademark of Apple, Inc. Smart Way® is a registered trademark of the U.S. Environmental Protection Agency. Stitcher™ is a trademark of Stitcher™, Inc. TORSEN LSD® is a registered trademark of JTEKT TORSEN North America, Inc. SiriusXM® All Access Radio is a registered trademark of SiriusXM Radio, Inc. SiriusXM Traffic® and SiriusXM Travel Link® are registered trademarks of SiriusXM Radio, Inc. Added Security, Crosstrek, Forester and Outback are registered trademarks of Subaru of America, Inc. BRZ, EyeSight, Impreza, Lineartronic, Legacy, Subaru, SUBARU BOXER, WRX, STI and X-MODE are registered trademarks of Subaru Corporation. Confidence in Motion and SUBARU STARLINK are trademarks of Subaru Corporation.

# Table of Contents

---

2-5	<b>Getting Started</b>
6-7	<b>Instrument Panel</b>
8-11	<b>Gauges</b>
12-13	<b>Personalize</b>
14-19	<b>Controls</b>
20-21	<b>While Operating</b>
22-23	<b>Safety/In Case of Emergency</b>
24-26	<b>Additional Information</b>

# Remote Keyless Entry

## 1 Lock/Arm

- Press to lock all doors and the rear gate and activate the security alarm.
- If any of the doors or the rear gate are not fully closed, five rapid chirps will sound and the hazard lights will flash to alert you that the doors or the rear gate are not properly closed.
- To activate the vehicle finder function, press three times (within five seconds). If you are within 30 feet of the vehicle, the horn will sound one time and the hazard lights will flash three times.

## 2 Unlock/Disarm

- Press once to unlock the driver's door.
- Press twice (within five seconds) to unlock all doors.
- When the "Unlock/Disarm" button is pressed, the dome and map lights will illuminate if the dome light switch is in the middle position.

## 3 Unlocking the Rear Gate

- Press to unlock the rear gate. An electronic chirp will sound twice and the hazard lights will flash twice.

## 4 Panic Alarm

- Press once and the horn will sound and the hazard lights will flash.
- Press any button on the remote to deactivate.



## Keyless Access with Push Button Start System (if equipped)

By simply carrying the access key in your pocket, you can lock and unlock doors, open the rear gate and start your car without ever having to take the key fob out of your pocket.



# Seating

## Seat Controls

### ① Forward/Backward

Pull up on the lever below the front of the driver's seat to move the seat forward or backward.

### ② Raise/Lower Seat Cushion

To adjust the height of the driver's seat, pull up or push down the seat height adjustment lever, located on the lower left side front of the seat.

### ③ Recline Seatback

To adjust the seatback to the desired position, pull up on the recline lever, located on the lower left rear of the driver's seat or lower right rear of the passenger's seat. Do not adjust seats while driving.



Instrument Panel

Gauges

Personalize


Controls

While Operating

Safety/In Case of Emergency

Additional Information

# Seating



## Power Driver's Seat (if equipped)

### ① Forward/Backward, Angle and Height

Move the switch toward the front or rear to move the seat forward or backward. Pull the switch up or push down on the front of the switch to adjust the angle of the seat cushion. Pulling the switch straight up or pushing the switch straight down will adjust the height of the entire seat cushion.

### ② Seatback

Move the switch in the corresponding direction to adjust the angle of the seatback.

## Heated Seats (if equipped)

Switches are located on the center console between the driver's and passenger's seats; choose low (bottom of switch) for normal heating or high (top of switch) for rapid heating. Choose the center position to turn off the seat heaters.



## Folding the Rear Seat

Lower the headrests. Pull up on the release knob on the seat side that you want to fold down. To return the seatback to its original position, raise the seatback until it locks into place, making sure that it is securely locked.



Instrument Panel

Gauges

Personalize


Controls

While Operating

Safety/In Case of Emergency

Additional Information

# Instrument Panel



PAGE  
NUMBER


14, 20

18

12

8-11





19


16-17

**Clock**

Press the "+" button to advance the time or the "-" button to reverse the time. Vehicles with a navigation system, please refer to the separate "Operating Instructions for Navigation System."

# Gauges - Vehicles without EyeSight

- Immediate Attention
- Caution
- ■ Informational



Seatbelt warning



Brake system



Front passenger seatbelt warning



Hot coolant temperature/  
Cold coolant temperature



SRS airbag system



High beam indicator light



Security indicator light



AT OIL TEMP  
(Automatic Transmission)



Door open



ABS warning



Charge warning



Low fuel



Oil pressure warning




All-Wheel Drive  
(Automatic Transmission)



Power steering warning



Vehicle Dynamics Control/  
Vehicle Dynamics  
Control operation



Vehicle Dynamics Control OFF



Keyless Access with Push Button Start System (if equipped)



CHECK ENGINE/  
Malfunction indicator



Turn signals



Tire pressure warning light



Front fog light indicator light (if equipped)



Front passenger frontal airbag ON  
(Located on overhead console)



Hill descent control (if equipped)



Front passenger frontal airbag OFF  
(Located on overhead console)



Engine oil level warning light




Windshield washer fluid warning



Incline start assist

# Gauges - Vehicles with EyeSight

- Immediate Attention
- Caution
- ■ Informational



Seatbelt warning

**BRAKE** / Brake system



PASSENGER Front passenger seatbelt warning



Hot coolant temperature/  
Cold coolant temperature



SRS airbag system



High beam indicator light



Security indicator light



**AT OIL TEMP** AT OIL TEMP  
(Automatic Transmission)



Door open



**ABS** / ABS warning



Charge warning



Low fuel



Oil pressure warning




**AWD** All-Wheel Drive  
(Automatic Transmission)



Power steering warning



Vehicle Dynamics Control/  
Vehicle Dynamics  
Control operation



Vehicle Dynamics Control OFF



Pre-Collision Braking System OFF light



CHECK ENGINE/  
Malfunction indicator



Lane Departure Warning OFF light



Tire pressure warning light



Keyless Access with Push Button Start System (if equipped)



ON / Front passenger frontal airbag ON (Located on overhead console)



Turn signals



OFF / Front passenger frontal airbag OFF (Located on overhead console)



Front fog light indicator light (if equipped)



Engine oil level warning light



Headlight indicator light



Windshield washer fluid warning



Incline start assist

# Personalize

## Tilt and Telescopic Steering Column

Pull the lever down firmly to adjust the height and lengthwise position of the column; firmly push the lever back up to lock the column in place. Do not adjust while driving.



## Power Exterior Mirrors

Turn the knob to the “L” side to adjust the left-hand mirror or to the “R” side to adjust the right-hand mirror. Move the knob in the direction you want to move the mirror. Then return the knob to the neutral/center position.




## i/SET Combination Meter Display Controls (if equipped)

Use the controls to display and switch selected items in the combination meter display. Please refer to your Owner's Manual for details on these controls.



## Power Moonroof (if equipped)

With the moonroof in the fully closed position, press and hold the switch ① to tilt the rear of the moonroof up. Press and hold the switch ② to lower the moonroof. Press and hold the switch ③ to fully open the moonroof. Press and hold the switch ④ to close the moonroof. To stop the moonroof in a midway position while opening or closing, momentarily press the switch to side ③ or side ④.



## HomeLink® 5 Accessory Mirror (if equipped)

The HomeLink 5 accessory mirror provides three buttons to replace up to three hand-held radio frequency remotes used to activate devices such as garage door openers, gate openers, entry door locks, security systems and home lighting. Please see your Owner's Manual for programming instructions or visit [www.subaru.com/homelink](http://www.subaru.com/homelink) to view a how-to video.



# Controls


## Light Controls

Push forward to change from low beam to high beam. Pull the lever back to center to return to low beam.

Turns on headlights, instrument panel illumination, parking lights, tail lights and license plate lights.

Push slightly up for lane change or fully up for right turn signal.

Push slightly down for lane change or fully down for left turn signal.



Rotate to turn on fog lights (if equipped).

AUTO (if equipped): The vehicle's lights are automatically on or off, depending on the level of outside light.

Turns on instrument panel lights, tail lights, parking lights and license plate lights.

While the light switch is on, rotate the dial downward to dim the instrument panel illumination. Rotate the dial upward to make the illumination brighter. When the dial is fully rotated upward (dots aligned), the instrument panel illumination stays at full brightness.









## Windshield Wipers

To turn on the wipers, press the wiper control lever down one level for intermittent, two levels for low, or three levels for high speed. Return the lever to the “OFF” position to stop the wipers. For a single wipe, move the lever up. To spray washer fluid, pull and hold the lever toward you.

To operate the rear wiper, rotate the end of the knob upward to the intermittent, continuous, or wash position. When the rear wiper is off, rotate the knob downward to wash and wipe the rear window.

## Daytime Running Lights

Daytime running lights are standard on your vehicle. Only the front daytime running lights will be automatically turned on when the engine has started, the parking brake is fully released and the light switch is in the “OFF” or “” position. The brightness of the illumination of the high beam headlights is reduced by the daytime running light system. You must always switch on your headlights when it is dark outside by turning the light switch to the “” position or have the switch in the “AUTO” position.

# Controls



## Manual Climate Control System (if equipped)

### ① Air Flow Control Dial

The air flow control dial allows you to choose the direction of air flow. Rotate the dial for the desired air flow position.

#### Defrost/Defog

To clear the windshield and front door windows of fog or frost, rotate the air flow control dial to the defrost position, set the temperature control to the red position, and set the fan speed control to the fastest speed.

### ② Rear Window Defogger Button

Press the rear window defogger button to turn on the defogger. The defogger will automatically shut off after about 15 minutes. If the window clears before that time, you can press the button again to turn it off. If equipped, the outside mirror defogger and windshield wiper de-icer will also activate.

### ③ Fan Speed Control Dial

Rotate the fan speed control dial to select one of four fan speeds.

### ④ Recirculated/Outside Air Button


Press the air inlet selection button to prevent outside air from being drawn into the passenger compartment. If the button is pushed in, press it again to draw outside air into the compartment. TO PREVENT WINDSHIELD FOGGING, DO NOT REMAIN IN THE RECIRCULATED MODE FOR AN EXTENDED PERIOD OF TIME.

### ⑤ Temperature Control Dial

Rotate the temperature control dial from blue for cool, to red for warm.

### ⑥ Air Conditioning Button

Press the "A/C" button to activate the air conditioning. Press it again to turn off the air conditioning.



Located in the multi-function display; top center of dash

## Automatic Climate Control System (if equipped)

### ① Automatic On and Off

This system automatically controls outlet air temperature, fan speed, air flow distribution, air inlet control, and air conditioner compressor operation. Press “AUTO” to activate. Press “OFF” to turn off the system.

### ② Temperature Control Dial

Rotate the dial clockwise to increase the temperature or rotate the dial counterclockwise to decrease the temperature and maintain a comfortable climate within the driver and passenger compartment. The temperature is displayed digitally on the screen.

### Operation in Manual Mode

#### ③ Recirculated/Outside Air Button

Press the air inlet selection button to prevent outside air from being drawn into the passenger compartment. Press the button again to allow outside air into the compartment. TO PREVENT WINDSHIELD FOGGING, DO NOT REMAIN IN THE RECIRCULATED MODE FOR AN EXTENDED PERIOD OF TIME.

#### ④ Fan Speed Control Knob

Rotate the fan speed control

knob to select one of seven different fan speed positions.

#### ⑤ Air Flow Mode Selection Dial

Turn the “MODE” dial to select the desired air flow mode. The selected air flow mode – either ventilation, bi-level, heat or heat-defrost – is shown on the display.

#### ⑥ Air Conditioner Button

Press the “A/C” button to activate the air conditioning. Press it again to turn off the air conditioning.

#### ⑦ Defroster Button

Press the button to defrost or dehumidify the windshield and front door windows.

#### ⑧ Rear Window Defogger Button

Press the button to turn on the defogger. It will automatically shut off after about 15 minutes. If the window clears before that time, you can press the button again to turn it off. If equipped, the outside mirror defogger and windshield wiper de-icer will also activate.

#### ⑨ Maximum Air Conditioner Button

For quicker cooling, press the “MAX A/C” button.

# Controls

## Steering Wheel Audio Controls (if equipped)

With any of the radio modes selected, press the left or right arrow button to toggle through your presets. In CD mode, press the buttons to skip forward or back a track.



Push the switch up (+) to increase volume or down (-) to decrease volume.

Press the button to select the desired audio mode – FM, AM, SXM, CD, AUX, MEDIA.

Voice recognition switch; please refer to your Starlink Owner's Manual.

## USB Port

The USB port is located in the front of the center console. You can connect a portable music player to the USB port and hear the music stored on it through the vehicle speakers. Press the "SOURCE" button located on the audio system repeatedly until the USB mode is selected.




## Auxiliary Input Jack


The 3.5mm auxiliary input jack is located in the front of the center console. You can connect a portable music player to the auxiliary jack and hear the music stored on it through the vehicle speakers. Press the "SOURCE" button located on the audio system to select the auxiliary mode.

## Cruise Control

To resume your speed after canceling, push the switch to the “RES” side.

To activate the cruise control, press the “” button.

The indicator light on the instrument panel will turn on.

To deactivate cruise control, press the “” button again.



Press the accelerator pedal until your vehicle reaches the desired speed. Push the switch to the “SET” side and release. Ease off the accelerator pedal. Your vehicle will maintain the desired speed.

To cancel the cruise control, push the brake pedal or press the “CANCEL” button. If you have a manual transmission, you can push in the clutch pedal.

### Increase Speed

Push up the “RES/SET” switch to the “RES” side; hold until your vehicle reaches the desired speed and release. To increase speed using the accelerator pedal, press the pedal until you reach the desired speed. Push down the “RES/SET” switch to the “SET” side to set the speed.

### Decrease Speed

Push down the “RES/SET” switch to the “SET” side; hold until your vehicle slows to the desired speed and release. To decrease the speed using the brake pedal, press the pedal to release cruise control temporarily. When the speed decreases to the desired speed, push down the “RES/SET” switch to the “SET” side to set the speed.

# While Operating



## Instrument Panel Switches (lower left)

Please refer to your Owner's Manual for details on these switches.

- ① Steering Responsive Headlights OFF switch (if equipped)
- ② Traction Mode/Vehicle Dynamics Control OFF switch
- ③ Blind Spot Detection/Rear Cross Traffic Alert OFF switch (if equipped)

## Paddle Shift Control Switches (if equipped)

- Temporary use: Even when the selector is in the "D" (Drive) position, you can temporarily shift the gear by pulling the "+" or "-" paddle shift control switch. The transmission will automatically switch back to Normal Mode.
- When the selector lever is in Manual Mode, shift to the next higher gear by pulling the "+" paddle shift control switch on the steering wheel. Pull the "-" paddle shift control switch to shift into the next lower gear.



## Manual Shifting Operation

Arrow-shaped lights in the center of the instrument panel show whether an upshift is possible and whether a downshift is possible.



## Automatic Transmission Shift Mode

The automatic transmission gives you ultimate control with two different driving modes: Normal Mode and Manual Mode.

### Normal Mode

When the selector lever is in the “D” (Drive) position, the transmission is in Normal shift mode. The shift position indicator on the instrument panel shows “D”, and the transmission automatically shifts into a suitable forward gear.

### Manual Mode

In Manual Mode, you select the desired gear position to obtain necessary acceleration and engine braking. Moving the selector lever left into the manual gate ① from the “D” (Drive) position causes the transmission to change into Manual Mode. To shift, use the paddle shift control switches. The shift position indicator shows the selected gear position.

## X-MODE® (if equipped)

X-MODE® is the integrated control system of the engine, AWD and Vehicle Dynamics Control system. Press the X-MODE button to activate. Press it again to deactivate. Please refer to your Owner’s Manual for operational parameters and details about this feature.



# Safety/In Case of Emergency



## Child Restraint System

Your vehicle is equipped with Lower Anchors and Tethers for Children (LATCH). For maximum safety, first carefully read the LATCH system instructions from the device manufacturer, as well as the installation instructions in your Owner's Manual, to properly install the LATCH compatible restraint system. Use the appropriate seatbelts or anchorages provided in your vehicle. Children age 12 and under must properly occupy the rear seat at all times.

## Child Safety Locks

The child safety locks are located on the inside edges of the rear doors. In the locked position, the rear doors can only be opened from the outside.







## Location of Spare Tire and Jack

A jack handle is stored under the floor of the cargo area. A jack and a towing hook are stored in the tool bucket in the center of the spare tire. Also, a tool bag that contains a wheel nut wrench and a screwdriver is included with the vehicle.

## Emergency Towing Your All-Wheel Drive Vehicle

Since Subaru Symmetrical All-Wheel Drive distributes engine power to all four wheels, improper towing will severely damage your AWD system. A flatbed truck is the only recommended way to properly transport your AWD vehicle. If towing is necessary, it is best done by your Subaru Retailer or a commercial towing service.

## Subaru Roadside Assistance

Subaru Roadside Assistance is free and standard on every 2018 Subaru vehicle. Coverage is automatic; there are no forms to complete. Subaru Roadside Assistance is available anytime during the 3-year/36,000-mile Subaru Limited Warranty, whichever comes first.\* A Subaru Roadside Assistance decal has been affixed to the driver's door window.

Subaru Roadside Assistance:  
1-800-261-2155

### Exclusions

Specifically excluded from Subaru Roadside Assistance coverage are service requests or claims resulting from: accidents, vandalism, acts of God, violation of any laws, misuse and abuse, or vehicle modifications not recommended by the manufacturer.

\*See your Retailer for details.

# Additional Information

## Fuel

- Use regular unleaded gasoline with an octane rating of 87 AKI or higher. Consult the Owner's Manual for more detailed information.

## Fuel Capacity

- 16.6 US gal (63 liters, 13.9 Imp gal)
- When the low fuel indicator light is displayed on the instrument panel, approximately 2.5 US gal (9.5 liters, 2.1 Imp gal) of fuel remain.
- If you have recently fueled your vehicle, the Check Engine light on the instrument panel may stay on due to a missing or loose fuel filler cap (the cap should be tightened until a click is heard).

## Fuel Filler Lid Release

The fuel filler lid release is located on the floor to the left of the driver's seat. To open the fuel filler lid, pull the fuel filler lever up and release.



## Engine Oil

Use only the following oils:

- ILSAC GF-5, which can be identified with the ILSAC certification mark (Starburst mark).
- Or API classification SN with the words “RESOURCE CONSERVING.”
  - Use 0W-20 synthetic, replacement interval 6,000 miles under normal driving conditions. No requirement at the first 3,000 miles.


## Engine Oil Capacity

- 4.7 US qt (4.4 liters, 3.9 Imp qt)

# Engine Compartment

Please refer to your Owner's Manual for more information.

## 2.0i Engine



① Brake Fluid Reservoir

② Main Fuse Box

③ Battery

④ Windshield Washer Tank

⑤ Radiator Cap

⑥ Engine Oil Filler Cap

⑦ Engine Coolant Reservoir

⑧ Engine Oil Filter

⑨ Engine Oil Dipstick

⑩ Air Cleaner Element





One Subaru Drive  
Camden, NJ 08103-9800



MSA5B1907A  
Issued May 2018  
Printed in USA 05/18

