



Technical Service Bulletin: TSB260065

Released Date: 26-May-2026

Reflash ECM Calibration requirement after replacing Aftertreatment Outlet Oxygen Sensors

Reflash ECM Calibration requirement after replacing Aftertreatment Outlet Oxygen Sensors

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents

Product Affected

- X15N CM2380 X150B

Fault Codes / Symptoms

- FC1862
- FC1863
- FC2688
- FC2689
- FC4749
- FC4751
- FC5656

Issue Summary

Fault Codes can appear directly after replacing the aftertreatment outlet oxygen sensor.

Verification/Confirmation

Verify the aftertreatment outlet oxygen sensor was just replaced.

Resolution

The ECM calibration code **must** be reflashed when the aftertreatment outlet oxygen sensor is replaced. If the ECM already contains the latest calibration revision, the same ECM calibration revision **must** be reinstalled. See corresponding service manual. Refer to 019-100 in Section 19.

Document History

Date	Details
2026-5-13	Module Created

Last Modified: 26-May-2026
