

WORK DESCRIPTION FOR FIELD MEASURE

Code: 26P5892224

Version: 2.0

Update Digital Operator's Manual and include printed Operator's Manual, renewing it if necessary

Model 206, 236, 254 and 295

- i** • Always use the **latest** XENTRY Diagnosis software release with all available add-ons.
- Make sure to follow the operation steps exactly as described in XENTRY Diagnosis!
- Use a battery charger to ensure a sufficient power supply is available for the vehicle's **on-board electrical system battery** (greater than 12.5 V).
- If XENTRY Diagnosis is already connected to the vehicle, start with **Work Procedure Step 2**.
- i** If two or more software updates or SCN codings are performed during one workshop visit, operation items 02-4762 and 02-5058 must **only be invoiced once for each workshop order!**

Work Procedure

i Update Digital Operator's Manual.

1. Connect XENTRY Diagnosis.

2. Update Digital Operator's Manual.

i To do this, select menu item "Quick test view → **A26/17 - MBUX multimedia system (head unit)** → Adaptations → Control unit update → Update control unit software".

i Then follow the user guidance in XENTRY Diagnosis.

i The Digital Operator's Manuals are downloaded automatically via Retail Data Storage to XENTRY Diagnosis to match the affected vehicle.

3. Disconnect XENTRY Diagnosis.

4. Check whether the Operator's Manual in the vehicle document wallet, as well as the supplements and accordion-fold document are present and whether the version is correct.

i Missing or incorrect Operator's Manuals, as well as supplements and accordion-fold document, must be replaced or enclosed as an aftermarket measure.

The Operator's Manual, supplements and accordion-fold document must be determined according to the equipment variant for the vehicle identification number via the parts process in the XENTRY Portal!

Parts

Quantity	Designation	Part no.
As required	Operator's Manual	*

* The replacement parts must be determined according to the equipment variant for the vehicle identification number via the parts process in the XENTRY Portal!

Operation text and target time

Operation no.	Operation text	Target time	Accounting no./ damage code
02-9445	Update Digital Operator's Manual	0.1	58 922 24
02-4762*	Connect/disconnect diagnostic system (XENTRY Diagnosis)	0.1	58 922 24
02-5058*	Connect/disconnect starter battery charger (XENTRY Diagnosis connected)	0.1	58 922 24
02-9471	Check owner's manual, include if necessary	0.1	58 922 24

* Operation item may be invoiced only once for each Repair Order!

Mercedes-Benz