News Channel Update

Vehicle Compliance & Analysis

TO: Mercedes-Benz Dealer Principals, General Managers,	FROM: Gregory Gunther, Department Manager, Vehicle	
Sales Managers, Service Managers, Parts Managers	Compliance and Analysis, Engineering Services	
RE: Service Campaign Launch Notification		
Update Transmission Control Unit Software	DATE: December 9, 2022	
MY16-17 Smart (453 platform)		

IMPORTANT SERVICE CAMPAIGN LAUNCH

Please note that all customer inquiries should be directed to the Customer Assistance Center at 1-800-FOR-MERCEDES (1-800-367-6372).

Sincerely,

Gregory Gunther

Department Manager, Vehicle Compliance & Analysis



Vehicle Compliance & Analysis

Service Campaign Launch Notification			December 9, 2022				
Campaign No.:	Campaign Desc. :	Undate	Transmission Control Unit Software				
2022110003	22P5496321	Opuate	Transmission Control Omit Software				
This is to notify you of the	This is to notify you of the Service Campaign Launch to update the transmission control unit software in 6,225 Model Year ("MY")						
2016-2017 Smart (453 platform) vehicles. The vehicles will be visible and flagged in VMI as "OPEN" on December 9, 2022.							
Background							
Issue		Mercedes-Benz AG ("MBAG"), the manufacturer of Mercedes-Benz, has determined that on certain MY 2016-2017 smart (453 platform) vehicles, the transmission control unit software does not correspond to current specifications. During scan tool readout, non-active errors may incorrectly output. These do not affect drivability and OBD errors are still detected correctly.					
What We're Doing		MBUSA will conduct a service campaign. An authorized Mercedes-Benz dealer will update the transmission control unit software.					
Parts	The		and can be performed as necessary.				
		Vehicles Affect	ed				
Vehicle Model Year(s)		2016-2017					
Vehicle Model		Smart					
		Vehicle Populati	ons				
Total Campaign Population	on 6,2	6,225					
Next Steps/Notes							
AOMS/SOMS		AOMs – This campaign	may generate questions from your dealers.				
While we regret any inconvenience this may cause, MBUSA is determined to maintain a high level of vehicle quality and customer satisfaction. Please refer all customer inquiries to the Customer Assistance Center at 1-800-FOR-MERCEDES.							



Service Campaign Bulletin



Campaign No. 2022110003, December 2022

Service Campaign Bulletin

Service Campaign Bulletin

TO: ALL MERCEDES-BENZ CENTERS

SUBJECT: Model Smart (453 platform)

Model Year 2016-2017

Update Electronic Transmission Control Unit Software

Mercedes-Benz AG ("MBAG"), the manufacturer of Mercedes-Benz, has determined that on certain MY 2016-2017 smart (453 platform) vehicles, the transmission control unit software does not correspond to current specifications. During scan tool readout, non-active errors may incorrectly output. These do not affect drivability and OBD errors are still detected correctly. An authorized Mercedes-Benz dealer will update the transmission control unit software.

Prior to performing this Campaign:

- VMI must always be checked before performing campaigns to verify that the campaign is required on a specific vehicle. Always check for any other open campaigns, and perform accordingly.
- Please review the entire Campaign bulletin and follow the repair procedure exactly as described.

Approximately 6,225 vehicles are affected.

Order No. P-SC-2022110003

This bulletin has been created and maintained in accordance with MBUSA-SLP S423QH001, Document and Data Control, and MBUSA-SLP S424HH001, Control of Quality Records.

Update electronic transmission control unit software

<u>i</u>	 Ensure use of XENTRY Diagnosis version BD/DVD (09/2022) or higher. Before starting the work procedure, install the current version of all add-ons in XENTRY Diagnosis. Make sure to follow the operation steps exactly as described in XENTRY Diagnosis. Use a battery charger to ensure sufficient power supply of the vehicle on-board electrical system
	battery (greater than 12.5 V).
	 If XENTRY Diagnosis is already connected to the vehicle, start with operation step 2.
	If two or more software updates or SCN codings are performed during one workshop visit, operation items 02-4762 and 02-5058 may be invoiced only once for each workshop order.
	only once for each workshop order.
Wo	ork Procedure
1.	Connect XENTRY Diagnosis.
2.	Update electronic transmission control unit software.
	To do this, select menu item "Quick test view – N15/13 Electronic transmission control – Adaptations – Control unit update – Update of control unit software."
	i Then follow the user guidance in XENTRY Diagnosis.
3.	Disconnect XENTRY Diagnosis.

Note: The following allowable labor operation should be used when submitting a warranty claim for this repair.

Warranty Information

Damage	Operation	Description	Labor Time (hrs.)
Code	Number		
	02-9334	Update electronic transmission control unit software (with XENTRY Diagnosis connected)	0.1
54 963 21	02-4762*	Connect/disconnect diagnostic system (XENTRY Diagnosis)	0.1
	02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1

Invoice operation item only once for each workshop order.

Note: Always check ASRA for the current OP-Code times. Labor times are subject to change and updates may not be reflected in this document.