




# WORK DESCRIPTION FOR FIELD MEASURE

Code: 20P5892111



Version: 2.0

## Update Digital Operator's Manual

Model 253 with code 801

-  • Code 801 corresponds to modification year 2020/1
  
-  • Ensure use of **XENTRY Diagnosis version** BD/DVD (**09/2020**) or higher.
- Before starting the work procedure, install all the **add-ons that are updated daily** in **XENTRY Diagnosis**.
- Make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
- Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
- If XENTRY Diagnosis is already connected to the vehicle, start with **operation step 2**.
  -  If two or more software updates or SCN codings are performed during one workshop visit, the operation items 02-4762 and 02-5058 may only be invoiced **once for each workshop order!**

## Work procedure

1. Connect XENTRY Diagnosis.
2. Update **COMAND Online (head unit)** control unit software.
  -  To do this, select menu item "Quick test view – COMAND Online (head unit) – Adaptations – Initial control unit startup – Initial startup of the already installed control unit".
  -  Then follow the user guidance in XENTRY Diagnosis.
3. Disconnect XENTRY Diagnosis.

## Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9445	Update Digital Operator's Manual (with XENTRY Diagnosis connected)	0.1 hours	58 921 11
02-4762*	Connect/disconnect vehicle diagnosis system (XENTRY Diagnosis)	0.1 hours	58 921 11
02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 hours	58 921 11

\* Operation item may only be invoiced once for each workshop order!