

# WORK DESCRIPTION FOR FIELD MEASURE

Code: 22P5891308

Version: 2.0

**Update Digital Operator's Manual and enclose printed Operator's Manual, replace if necessary**  
Model 177, 243, 247

---

- i** • Always use the **latest** XENTRY Diagnosis software release with all available add-ons.
  - Make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
  - Use a charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
  - If XENTRY Diagnosis is already connected to the vehicle, start with **operation step 2**.
- i** If two or more software updates or SCN codings are performed during one workshop visit, the operation items 02-4762 and 02-5058 may only be invoiced **once for each workshop order**.

## Work procedure

**i** Update Digital Operator's Manual.

1. Connect XENTRY Diagnosis.

2. Update Digital Operator's Manual.

**i** To do this, select menu item "Quick test view – **MBUX control unit** – Adaptations – Control unit update – Update of control unit software".

**i** Then follow the user guidance in XENTRY Diagnosis.

**i** The Digital Operator's Manuals are automatically downloaded via the Retail Data Storage to XENTRY Diagnosis matched to the affected vehicle.

3. Disconnect XENTRY Diagnosis.

4. Check the Operator's Manual present in the vehicle document wallet, as well as whether the supplements and ACCORDION-FOLD DOCUMENT are present and whether the part number is correct.

**i** The missing or incorrect Operator's Manual, as well as supplements and ACCORDION-FOLD DOCUMENT must be replaced or enclosed as an aftermarket measure.

The Operator's Manual, as well as supplements and ACCORDION-FOLD DOCUMENT must be determined according to the equipment variant for the vehicle identification number via the parts process in the Xentry Portal.

**Operation text and flat rate**

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9445**	Update Digital Operator's Manual (with XENTRY Diagnosis connected)	0.1 h	58 913 08
02-4762*	Connect/disconnect diagnostic system (XENTRY Diagnosis)	0.1 h	58 913 08
02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	58 913 08
02-9471**	Check operator's manual, enclose if necessary	0.1 h	58 913 08

\* Operation item may only be invoiced once for each workshop order!

\*\* Please manually enter the code 22P5891308 and accounting number 58 913 08 in the workshop order as per the work instructions.

Mercedes-Benz  
Global Service & Parts